



Allen-Bradley

FLEX Ex Analog Modules

1797-IE8, -IE8NF, and -OE8

User Manual

**Rockwell
Automation**

Important User Information

Solid state equipment has operational characteristics differing from those of electromechanical equipment. *Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls* (Publication SGI-1.1 available from your local Rockwell Automation sales office or online at <http://www.ab.com/manuals/gi>) describes some important differences between solid state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc. is prohibited.

Throughout this manual we may use notes to make you aware of safety considerations.

WARNING



Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.

IMPORTANT

Identifies information that is critical for successful application and understanding of the product.

ATTENTION



Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you:

- identify a hazard
 - avoid a hazard
 - recognize the consequence
-

SHOCK HAZARD



Labels may be located on or inside the equipment to alert people that dangerous voltage may be present.

BURN HAZARD



Labels may be located on or inside the equipment to alert people that surfaces may be dangerous temperatures.

The information below summarizes the changes to this manual since the last printing.

To help you find new and updated information in this release of the manual, we have included change bars as shown to the right of this paragraph.

The table below lists the sections that document new features and additional or updated information about existing features.

For this information	See
New Related Publications	P-2
EMC Directive	3-2
ATEX Directive	3-2
Installation in Zone 1	3-3
Installation in Zone 22	3-3
1797-IE8 and -IE8NF Specifications	A-1
1797-IE8 and -IE8NF UL, C-UL I/O Entity Parameters	A-4
1797-IE8 and -IE8NF FM I/O Entity Parameters	A-7
1797-OE8 Specifications	A-10
1797-OE8 UL, C-UL I/O Entity Parameters	A-12
1797-OE8 FM I/O Entity Parameters	A-15

Notes:

Table of Contents

Preface	Why Read This Manual	P-1
	Who Should Read This Manual.	P-1
	About the Vocabulary	P-1
	What This Manual Contains	P-1
	For Additional Information.	P-2
About the FLEX Ex Analog Modules	Chapter 1	
	What this Chapter Contains.	1-1
	What the FLEX Ex Analog I/O Modules Do.	1-1
	How FLEX Ex Analog Modules Communicate with Programmable Controllers	1-2
	Events following Power-Up	1-2
	Physical Features of Your Analog I/O Module	1-3
	Indicators	1-3
	Using Alarms on the 1797-IE8 and -IE8NF Modules.	1-3
	Data Format Alarm Example	1-4
	Overrange Alarm	1-4
	Underrange Alarm	1-4
	Remote Fault Alarm	1-5
	Local Fault Alarm	1-6
	Chapter Summary.	1-6
Understanding Configurable FLEX Ex Analog Module Features	Chapter 2	
	What this Chapter Contains.	2-1
	Selecting a 1797-IE8 or -IE8NF FLEX Ex Analog Input Module's Operating Features	2-2
	Fault Mode.	2-2
	Remote Transmitter Error Up or Down	2-3
	High Low Error Level.	2-3
	Input Filter Cutoff.	2-3
	Data Format.	2-4
	Selecting a 1797-OE8 FLEX Ex Analog Output Module's Operating Features.	2-7
	Output Enable	2-7
	Local Fault Mode.	2-7
	Latch Retry Mode	2-8
	Global Reset.	2-8
	Analog Digital State.	2-8
	Analog Fault State	2-9
	Digital Fault State.	2-9
	Data Format.	2-10
	Fault Alarm	2-12

Understanding Image Table Mapping and Bit/Word Descriptions	2-13
Bit Descriptions	2-13
Analog Input Modules (1797-IE8 and -IE8NF) Image Table Mapping	2-14
Bit/Word Description for the Analog Input Modules (1797-IE8 and -IE8NF)	2-15
Analog Output Module (1797-OE8) Image Table Mapping	2-16
Bit/Word Descriptions for the Analog Output Module (1797-OE8)	2-17
Chapter Summary	2-18

Chapter 3

How to Install Your FLEX Ex Analog Modules

What this Chapter Contains	3-1
Before You Install Your Analog Module	3-1
Compliance to European Union Directives	3-2
EMC Directive	3-2
ATEX Directive	3-2
Installation in Zone 1	3-3
Installation in Zone 22	3-3
Electrostatic Charge	3-3
Removal and Insertion Under Power	3-4
Installing the Module	3-4
Mounting on a DIN Rail	3-5
Panel/Wall Mounting	3-7
Mounting the Analog Modules on the Terminal Base Unit	3-9
Wiring the Terminal Base Units	3-10
Connecting Wiring to the FLEX Ex I/O Analog Modules	3-11
Inputs/Outputs	3-11
Connections for the 1797-IE8 and -IE8NF Modules	3-11
Connections for the 1797-OE8 Module	3-13
Grounding the Module	3-14
Chapter Summary	3-14

Input, Output, and Configuration Files for the Analog I/O Modules on the ControlNet Network

Chapter 4

What this Chapter Contains.	4-1
Using Programming Software in Your FLEX Ex Application	4-2
About the ControlNet Ex Adapter	4-2
Communication Over the FLEX Ex Backplane.	4-3
Scheduled Data-Transfer.	4-3
Unscheduled Data-Transfer	4-3
Module I/O Mapping	4-4
I/O Structure	4-4
Adapter Status Word	4-5
Fault State Data	4-6
Device Actions	4-6
Communication Fault Behavior	4-7
Idle State Behavior.	4-7
Input Data Behavior upon Module Removal.	4-8
Chapter Summary.	4-8

Calibrating Your Module

Chapter 5

What This Chapter Contains	5-1
When and How to Calibrate Your FLEX Ex Analog I/O Module	5-1
Tools and Equipment	5-2
Using Calibration Module Command Words	5-2
Typical MODULE Calibration Command Word	5-3
Calibrating the Input Modules.	5-6
Calibrating the Output Modules	5-8
Chapter Summary.	5-10

Applying FLEX Ex Analog I/O Modules

Chapter 6

What this Chapter Contains.	6-1
Evaluate the Application	6-1
Define the Area Classification.	6-2
Decide Classification Method	6-2
Determine Hazard	6-2
Determine Temperature Rating	6-2
Select Protection Method(s)	6-3
Match Field Devices and I/O Modules	6-3
P/I Analog Transmitter Functional and IS Parameters.	6-3
1797-IE8 and -IE8NF Functional and IS Parameters	6-4
Loop Functionality Verification	6-4
Intrinsic Safety Entity Verification	6-6
I/O	6-7
Optimize Power Distribution	6-7
Assigning Power Supplies	6-7
Power Supply Considerations	6-9
Chapter Summary.	6-9

Troubleshooting the FLEX Ex Analog I/O Modules

Chapter 7

What this Chapter Contains.	7-1
Status Indicators.	7-1
1797-IE8 and -IE8NF Modules	7-1
1797-OE8 Module.	7-2
Repair	7-2
Chapter Summary.	7-2

Specifications

Appendix A

1797-IE8 and -IE8NF Input Modules	A-1
Specifications	A-1
1797-IE8 and -IE8NF CE, CENELEC I/O Entity Parameters	A-3
1797-IE8 and -IE8NF UL, C-UL I/O Entity Parameters	A-4
1797-IE8 and -IE8NF FM I/O Entity Parameters	A-7
1797-OE8 Output Module	A-10
Specifications	A-10
1797-OE8 CENELEC I/O Entity Parameters	A-11
1797-OE8 UL, C-UL I/O Entity Parameters	A-12
1797-OE8 FM I/O Entity Parameters.	A-15

Index

Why Read This Manual

This manual shows you how to use your FLEX Ex™ analog modules with the ControlNet Ex™ products and ControlNet network. The manual helps you install, program, and troubleshoot your module.

Who Should Read This Manual

You must be able to program and operate a ControlNet Ex product and ControlNet™ network to make efficient use of a FLEX Ex module.

About the Vocabulary

In this manual, we refer to the:

- 1797-IE8 and -IE8NF as the “input modules”
- 1797-OE8 as the “output module”

What This Manual Contains

The following chart lists each chapter with its corresponding title and a brief overview of the topics covered in that chapter.

Chapter	Title	Contents
1	About the FLEX Ex Analog Modules	Describes module functionality and physical features
2	Understanding Module Features	Describes configurable module features and configuration bits
3	How to Install Your Analog Module	How to install and wire the modules
4	Input, Output and Configuration Files for the Analog I/O Modules on the ControlNet network	Describes how to use these I/O modules over the ControlNet network
5	Calibrating Your Module	Lists the tools needed, and the methods used to calibrate the module
6	Applying FLEX Ex Analog I/O Modules to the System	Describes how FLEX Ex is different from traditional control systems
7	Troubleshooting Your Module	How to use the indicators to troubleshoot your module
Appendix	Title	Contents
A	About the Specifications	Outlines module specifications and accuracy
B	Programming the FLEX Ex I/O Modules Using RIO	Explains how to program the analog modules

For Additional Information

For additional information on FLEX Ex systems and modules, refer to the following documents.

Catalog Number	Description	Publications	
		Installation Instructions	User Manual
1797 Series	FLEX Ex Selection Guide	1794-SG002	
1797 Series	ControlNet Ex System Cable Guide	1797-6.2.1	
1797-TB3	FLEX Ex Terminal Base	1797-5.1	
1797-TB3S	FLEX Ex Spring Clamp Terminal Base		
1797-OE8	FLEX Ex 8 Output Analog Module	1797-5.3	1797-6.5.1
1797-OE8H	FLEX Ex HART 8 Ouput Analog Module		1797-6.5.3
1797-IRT8	FLEX Ex RTD/Thermocouple/mV Module	1797-5.4	1797-6.5.2
1797-IE8	FLEX Ex 8 Input Analog Module	1797-5.5	1797-6.5.1
1797-IE8NF	FLEX Ex 8 Input Analog Module with Noise Filter		
1797-IE8H	FLEX Ex HART 8 Input Analog Module		1797-6.5.3
1797-OB4D	4 Output Module	1797-5.6	
1797-IBN16	FLEX Ex NAMUR Digital Input Module	1797-5.7	
1797-PS2E2	FLEX Ex Power Supply	1797-5.8	
1797-IJ2	2 Frequency Input Module	1797-5.9	1797-6.5.4
1797-PS2N2	FLEX Ex Power Supply	1797-5.12	
1797-BIC	FLEX Ex Bus Isolator	1797-5.13	
1797-CEC	FLEX Ex Flexbus Connector		
1797-ACNR15	ControlNet Ex Adapter	1797-5.14	1797-6.2.1
1797-RPA, -RPFM	Fiber Hub	1797-5.15	
1797-TPR, -TPRS, -TPYR, -TPYS	FLEX Ex Taps	1797-5.18	
1797-CE1S, -CE3S, -CEFTN, -CEFTE	Interconnect Cables	1797-5.20	
1797-EXMK	Marker Kit	1797-5.23	
1797-PS1E	FLEX Ex Power Supply	1797-5.33	
1797-PS1N	FLEX Ex Power Supply	1797-5.34	
1797-BCNR	FLEX Ex Redundant ControlNet Barrier Module	1797-5.35	

About the FLEX Ex Analog Modules

What this Chapter Contains

Read this chapter to familiarize yourself with the input and output analog modules.

For information on:	See page:
What the FLEX Ex Analog I/O Modules Do	1-1
How FLEX Ex Analog Modules Communicate with Programmable Controllers	1-2
Physical Features of Your Analog I/O Module	1-3
Chapter Summary	1-6

What the FLEX Ex Analog I/O Modules Do

The 1797-IE8 and -IE8NF modules accept up to 8 analog inputs. The inputs are non-isolated and will accept current in either of the following two ranges: 4-20mA or 0-20mA. The default input range is 0-20mA. The inputs have both fixed hardware filters and selectable firmware digital filters.

Similarly, the 1797-OE8 module provides as many as 8 analog outputs. The outputs are nonisolated and will provide current in either of the following two ranges: 4-20mA or 0-20mA. The default output range is 0-20mA.

Each module offers:

- local microprocessor intelligence for advanced features
- full functionality without switches or jumpers
- multiple data ranges that can be independently programmed in channel groups
- lead breakage detection
- overrange/underrange alarms
- remote transmitter alarm

as well as a host of other module features.

How FLEX Ex Analog Modules Communicate with Programmable Controllers

FLEX Ex analog I/O modules provide best utility when used with ControlNet Ex products on the ControlNet network. Data connections are established between the I/O module and an Allen-Bradley programmable controller to transfer information between the two at a scheduled rate.

Input module information is then automatically made available in the PLC data table through the data connection. Reciprocally, output data information determined by the PLC program is also automatically transferred from the PLC data table to the output module through the data connection.

In addition, when the data connection is originally established, configuration information for the module is automatically transferred to it via the network.

Events following Power-Up

You must apply intrinsically safe +/-V power to your FLEX Ex analog I/O modules. The following sequence of events occurs after power has initially been applied to your module:

1. The module begins an internal diagnostic check. The channel 0 LED indicator turns ON to indicate the check has begun. The indicator turns OFF when the check is finished.
2. After the diagnostic check, module configuration information, selected by the user and downloaded over the network, is applied by the module.

For more information on configuration options, see Chapter 2.

3. Following the module configuration download for the **1797-IE8 or -IE8NF modules**, the module begins producing runtime data for the PLC.

Following the module configuration download for the **1797-OE8 module**, the module applies configuration data to output channels.


4. If any diagnostics or alarms are generated during normal module operation, the data is returned to the PLC.

Physical Features of Your Analog I/O Module

The module label identifies the keyswitch position, wiring and module type. Use the removable label to note individual designations per your application.

Indicators

Indicators are provided to identify input or output fault conditions, and to show when power is applied to the module. For example, the 1797-IE8 module is shown below.



Using Alarms on the 1797-IE8 and -IE8NF Modules


The 1797-IE8 and -IE8NF FLEX Ex modules are capable of generating four alarms:

- Underrange
- Overrange
- Remote Fault
- Local Fault

These alarm conditions are described in general terms and as they relate to bits on the FLEX Ex I/O module on the following pages. The following graphic shows at what values these alarms are generated for Data Format 4.

Data Format Alarm Example

In this example, the normal active data range is 4-20mA. The alarms are generated in three overlapping bands.



Overrange Alarm

The Overrange alarm notifies you when module input is overrange. When the input signal exceeds 100% (20mA), an Overrange Alarm is generated.

This alarm stays active at any value above 100% of range and is always enabled by the module.

Underrange Alarm

The Underrange alarm works in a fashion converse to the overrange. This feature notifies you when the input signal falls underrange. If the input signal falls below 0% (4mA), an Underrange Alarm is generated.

This alarm stays active at any value below 0% of range and is always enabled by the module.

Remote Fault Alarm

The Remote Fault Alarm is primarily intended for use with remote transmitter loops.

For example, the remote transmitter may be measuring temperature and converting it to a standard mA signal. In such a loop, though, the input module cannot determine the state of the loop on the far side of the transmitter. However, the remote transmitter may be capable of diagnosing a problem in the remote loop and signal the input module local loop with a preprogrammed out of range (high or low) value.

The Remote Fault Alarm allows the 1797-IE8 and -IE8NF modules to work with transmitters like the one just described. You must use the Remote Transmitter Error Up or Down feature, see page 2-3, to configure your application for Remote Fault notification.

For example, you must determine if you want a remote fault to cause high out of range values or low out of range values to be returned to the controller.

IMPORTANT

Once the alarm is issued, it remains active as long as the input signal value remains above the programmed value.

Using Remote Fault Alarm to Determine High High or Low Low Alarm Levels

If you do not have a remote transmitter in your loop, this alarm can also be used to program a high high or low low alarm level between the levels which actuate the overrange or underrange alarms and the high or low local fault alarms.

IMPORTANT

When establishing high high or low low alarms, you can only select one side (high or low). You must use the Remote Transmitter Error Up or Down feature in conjunction with this alarm.

Programming the Remote Fault Alarm

For the Remote Fault alarm, you must program the threshold in 0.1mA steps at any level on the high or low end of input signal range. The Remote Fault alarm activates if your I/O module receives input signal values of:

- 100.63% (20.1mA) to 111.88% (21.9mA) on the high end of input signal range
- or
- -0.63% (3.9mA) to -11.88% (2.1mA) on the low end of input signal range

IMPORTANT

This alarm is only active for one band, either on the high side of normal operation or the low side. The Remote Transmitter Error Up/Down parameter determines which side is active. See page 2-3 for a description of the Remote Transmitter Error Up/Down feature.

Local Fault Alarm

The Local Fault alarm notifies you when the loop to the transmitter or field device, if no transmitter is used, is open or shorted.

IMPORTANT

Once the alarm is issued, it remains active as long as the input signal value remains in the programmed range.

- 112.50% (22mA) or higher on the high end of input signal range - This value indicates a short in the loop.
- or
- -12.50% (2mA) or lower on the low end of input signal range - This value indicates an open wire condition in the loop.

The Remote Fault and Local Fault alarms are issued with the same bit whether the cause is an under or overrange. Monitor the Overrange and Underrange bits in your programming software to determine if the problem is a high current or low current.

Chapter Summary

In this chapter, you learned what FLEX Ex analog I/O modules do. Move on to Chapter 2 to learn about configurable features on your module.

Understanding Configurable FLEX Ex Analog Module Features

What this Chapter Contains

Read this chapter to familiarize yourself with configurable features on the input and output analog modules.

For information on:	See page:
Selecting a 1797-IE8 or -IE8NF FLEX Ex Analog Input Module's Operating Features	2-2
Selecting a 1797-OE8 FLEX Ex Analog Output Module's Operating Features	2-7
Understanding Image Table Mapping and Bit/Word Descriptions	2-13
Chapter Summary	2-18

Use the table below to see what features this chapter describes.

Table 2.1 Configurable Features on the FLEX Ex Analog I/O Modules

1797-IE8 and -IE8NF input module features:	1797-OE8 output module features:
Fault Mode	Output Enable
Remote Transmitter Error Up or Down	Module Fault State Mode
High Low Error Level	Local Fault Mode
Input Filter Cutoff	Digital Output
Data Format	Latch Retry Mode
	Global Reset
	Analog Digital State
	Analog Fault State
	Digital Fault State
	Data Format
	Fault Alarm

You must use the I/O configuration portion of your PLC programming software to select and configure these features. This manual assumes familiarity with the programming software. A brief description of each module feature is provided here. For more information on your programming software, see the software user manual.

Selecting a 1797-IE8 or -IE8NF FLEX Ex Analog Input Module's Operating Features

All features of the 1797-IE8 and -IE8NF analog input modules are independently configurable in two four-channel groups (channel 0-3 & channel 4-7).

IMPORTANT

The default selection value for all parameters is 0.

Fault Mode

Your input modules are capable of indicating various fault conditions, depending on the input signal value. Use the Fault Mode feature to enable or disable two alarms:

- Remote Fault alarm
- Local Fault alarm

Use your programming software to set the Fault Mode bit to 0 to disable these alarms. Set the bit to 1 to enable them.

IMPORTANT

Fault Mode will only enable or disable the Remote and Local Fault alarms. It does not affect the Underrange and Overrange alarms. They are always active.

For more information on Remote and Local Fault alarms, see page 1-5.

Remote Transmitter Error Up or Down

A second feature of your input modules that affects use of the Remote Fault alarm is the Remote Transmitter Error Up or Down feature. Used in conjunction with the High Low Error level, this feature designates whether remote faults are displayed with input signal readings beyond the high or low signal levels normally used by the module.

When setting the Remote Transmitter Error Up or Down feature in your programming software, set this feature's bit to 0 to select up. Set the bit to 1 to select down.

For more information on Remote and Local Fault alarms, see page 1-5.

High Low Error Level

High Low Error level sets the high and low signal levels at which your input modules will indicate a signal fault. This feature works in conjunction with the Remote Transmitter Error Up or Down.

If the Remote Fault Alarm feature is enabled and a remote fault occurs, the module will detect and report the fault, depending on how the High Low Error level is configured.

Use your programming software to set the high or low error levels.

Input Filter Cutoff

Eight available input filter settings allow you to choose the best rolloff frequency for input channels on your I/O module. When choosing a filter, remember that time filter selection affects your input signal's accuracy.

For example, if you choose the highest frequency of 1200Hz (filter 0), signal noise is more likely to affect the reading, but the slowest frequency of 0.5Hz (filter 7) provides the most accurate signal due to incoming noise filtering.

See Table 2.2 to decide which input filter to use in your FLEX Ex analog I/O application:

Table 2.2 Input Filter Frequency

Filter:	7	6	5	4	3	2	1	0
1797-IE8 Frequency:	0.5Hz (2s)	1Hz (1s)	2Hz (500ms)	4Hz (250ms)	10Hz (100ms)	20Hz (50ms)	40Hz (25ms)	1200Hz (0.8ms)
1797-IE8NF Frequency:						Reserved		

Choose the best input filter cutoff in your programming software.

Data Format

You must choose a module data format in your user program. See Table 2.3 on page 2-4 for an explanation of each bit. Formats 8, 9, 10 and 15 are not used. If they are selected for a channel quad, a configuration fault will occur and will be reported as Diagnostic Data “2”. All data for that channel quad will be set to zero (0).

When using Table 2.3, remember the following:

- Formats 5, 12, 13 and 14 are 2's complement data formats, and will return data in that form.
- 12 Formats are available
- Default format is 0-20mA
- The data format selected interprets input readings and returns them to the PLC

Table 2.3 1797-IE8 and -IE8NF Data Formats


Data Format	Format	Resolution	Input Range	Module Data Processing	Data Table Value (interpretation)	Count per mA	Error Steps
0	0-20mA as mA	0.1% of 0-20mA	0-22mA	datatable = 1,000 (input)	0-22000 (0-22.000mA)	1000	with error steps
1	0-20mA as %	0.2% of 0-20mA	0-22mA	$\text{datatable} = 10,000 \left(\frac{\text{input}}{20} \right)$	0-11000 (0-110.00%)	500	with error steps
2	0-20mA as $\sqrt{\%}$	0.19% of 0-20mA	0-22mA	$\text{datatable} = 10,000 \sqrt{\frac{\text{input}}{20}}$ IF . . . Square_Root_Threshold $< 10,000 \sqrt{\frac{\text{input}}{20}}$ Else . . . datatable = 0	0-10488 (0-104.88%)	524	with error steps
3	0-20mA as unsigned integer	0.03% of 0-20mA	0-20mA	$\text{datatable} = 65,535 \left(\frac{\text{input}}{20} \right)$	0-65,535 (0-22mA)	3276	with error steps
4	4-20mA as mA	0.1% of 4-20mA	2-22mA	datatable = 1,000 (input)	2000-22000 (2.000-22.000mA)	1000	with error steps

Table 2.3 1797-IE8 and -IE8NF Data Formats

Data Format	Format	Resolution	Input Range	Module Data Processing	Data Table Value (interpretation)	Count per mA	Error Steps
5	4-20mA as %	0.16% of 4-20mA	2-22mA	$\text{datatable} = 10,000 \left(\frac{\text{input}-4}{16} \right)$	-1250 - +11250 (2's complement) (-12.50% - +112.50%)	625	with error steps
6	4-20mA as $\sqrt{\%}$	0.17% of 4-20mA	4-22mA	$\text{datatable} = 10,000 \sqrt{\frac{\text{input}-4}{16}}$ IF . . . Square_Root_Threshold $< 10,000 \sqrt{\frac{\text{input}-4}{16}}$ Else . . . datatable = 0	0-10607 (0-106.07%)	589	with error steps, under-range not allowed
7	4-20mA as unsigned integer	0.03% of 4-20mA	4-20mA	$\text{datatable} = 65,535 \left(\frac{\text{input}-4}{16} \right)$	0-65,535 (4-20mA)	4095	with error steps
8	0-20mA			not assigned			all fixed
9	0-20mA			not assigned			all fixed
10	0-20mA			not assigned			all fixed
11	0-20mA as A/D count	0.04% of 0-20mA	0-22mA	$\text{datatable} = 55,000 \left(\frac{\text{input}}{22} \right)$	0-55000 (0-22mA)	2500	all fixed
12	4-20mA as %	0.16% of 4-20mA	3.6-21mA	$\text{datatable} = 10,000 \left(\frac{\text{input}-4}{16} \right)$	-250 - +10625 (2's complement) (-2.50% - +106.25%)	625	NAMUR NE 4 all fixed
13	4-20mA as %	0.16% of 4-20mA	3-21mA	$\text{datatable} = 10,000 \left(\frac{\text{input}-4}{16} \right)$	-625 - +10625 (2's complement) (-6.25% - +106.25%)	625	all fixed
14	4-20mA as %	0.16% of 4-20mA	2-22mA	$\text{datatable} = 10,000 \left(\frac{\text{input}-4}{16} \right)$	-1250 - +11250 (2's complement) (-12.50% - +112.50%)	625	all fixed
15	4-20mA			not assigned			all fixed

Data Formats and Error Ranges

The graphic below shows the data formats and error ranges for your FLEX Ex analog I/O modules.



Selecting a 1797-OE8 FLEX Ex Analog Output Module's Operating Features

All features of the 1797-OE8 analog output module are independently configurable in two four-channel groups (channel 0-3 & channel 4-7).

IMPORTANT

The default selection value for all parameters is 0.

Output Enable

The Output Enable feature provides user control of the FLEX Ex I/O module's output channels.

At power-up, the ControlNet Ex adapter (1797-ACNR15) and the FLEX Ex I/O modules use a default state of no communications over the network. Use your programming software to change the Output Enable bit to 1 to begin communications over the network.

If network communication is ever lost during normal operations, the adapter resets the Output Enable bit to 0, and any connected I/O modules execute their fault routine, including transitioning to fault state and setting outputs to a user-defined fault state. When network communications resume, the adapter sets the Output Enable bit to 1 and normal I/O operations continue.

Local Fault Mode

The Local Fault Mode can be programmed to determine how the module responds to communications faults and internal module faults.

When setting the Local Fault Mode feature in your programming software, set this feature's bit to 0 to use the analog fault state or digital fault state only if a communications fault occurs. Set the bit to 1 to use the analog fault state or digital fault state if any fault occurs.

Latch Retry Mode

Latch Mode determines channel operation under wire off or lead break fault conditions. This feature controls the operation of two channel groups, channels 0-3 and channels 4-7. Channel detection occurs on a continuous basis. If a fault is detected, the channel fault alarm is set.

If Latch Mode is enabled when a fault occurs, the fault will remain latched in its fault state until a Global Reset (see below) is issued. If Latch Mode is disabled when a fault occurs, the channel reports a fault until the fault is corrected. Global Reset is not necessary if Latch Mode is disabled.

When using your programming software, set the Latch Mode bit to 0 to disable the feature. Set the bit to 1 to enable it.

Global Reset

Global Reset works in conjunction with Latch Mode during fault conditions. If Latch Mode is enabled and a fault condition occurs, the channel operating with a fault remains in this condition (with analog or digital fault state implied) until a Global Reset is issued. The Global Reset feature resets all outputs of a particular channel group to accept normal system output data.

The Global Reset feature is an edge triggered signal. Use your programming software to set the Global Reset bit to 1 for normal operation. Resetting of outputs occurs during the 1 to 0 transition.

Analog Digital State

You can configure your FLEX Ex analog I/O modules to work in an analog mode or digital mode using the Analog Digital State feature. Depending on which state you choose for your application, additional parameters (see the descriptions of Analog Fault State and Digital Fault State on page 2-9) must be configured for your module to react to fault conditions.

Set the Analog Digital State bit in your programming software to 0 for your module to operate in an analog state. Set the bit to 1 for your module to operate in a digital state. A selection bit is available to each channel.

Analog Fault State

The Analog Fault State feature determines how your I/O module reacts to faults when a channel is used in analog mode. After a fault condition occurs, the module may go to minimum value, maximum value, hold last state or 50% of range.

Use your programming software to set the Analog Fault State bits on the I/O module for one of the following fault reactions:

- 0 = minimum value
- 1 = maximum value
- 2 = hold last state
- 3 = 50% of range

You can set these parameters independently for channels 0-1, 2-3, 4-5, 6-7.

Digital Fault State

The Digital Fault State feature determines how your I/O module reacts to faults when a channel is used in digital mode. After a fault condition occurs, the module may reset channel outputs or hold last state of the outputs.

Use your programming software to set the Digital Fault State bit to 0 to reset outputs. Set to 1 to hold last state of the outputs after a fault occurs. This feature is available on a per channel basis.

Data Format

You must choose a module data format in your user program. See Table 2.4 on page 2-11 for an explanation of each bit. Data Formats 2, 5, 6, 8, 9, 10, 12 and 15 are not assigned.

When choosing a data format, remember the following:

- If a non-assigned Analog Data Format is selected, the module sets Diagnostic Data to “2” for configuration failure and puts affected channels affected in the corresponding fault state.
- An unconfigured module channel pair can be assumed to have the default configuration Analog Data Format “0”, 0-20mA and Analog Mode Fault State “minimum range”. If a non-assigned format is selected, then the diagnostic “2” for configuration failure is set and the module channel pair goes to the default fault state minimum range.
- If on the other hand, the configuration had been changed, from the default, and then it was changed again to a non-assigned format, then the diagnostic bit “2” for configuration failure is set and the module goes to the fault state for the last valid configuration.
- Formats 13 and 14 are 2’s complement data formats, and require data to the module in that form.
- Range: 0-15, See Table 13
- Default: 0
- Data Table Reference: data format, word 12 and 13, bits 0-3, bits 4-7

If data is sent to the module which is out of range, the value will be clipped and Diagnostic Data will be set to “11” data out of range. See the graphic below.




Table 2.4 1797-OE8 Data Formats

Data Format	Format	Resolution	Full Output Range	Module Data Processing	Data Table Value (Interpretation)	Count per mA	Analog Fault State
0	mA as 0-20mA	0.1% of 0-20mA	0-22mA	$\text{output} = \left(\frac{\text{datatable}}{1,000} \right)$	0-22000 (0-22.000mA)	1000	min=0mA max=22mA hold last=hold 50%=11mA
1	% as 0-20mA	0.2% of 0-20mA	0-22mA	$\text{output} = 20 \left(\frac{\text{datatable}}{10,000} \right)$	0-11000 (0-110.00%)	500	min=0mA max=22mA hold last=hold 50%=11mA
2	0-20mA		0-22mA	not assigned			
3	unsigned integer as 0-20mA	0.03% of 0-20mA	0-20mA	$\text{output} = 20 \left(\frac{\text{datatable}}{65,535} \right)$	0-65,535 (0-22mA)	3276	min=0mA max=20mA hold last=hold 50%=10mA
4	mA as 4-20mA	0.1% of 4-20mA	2-22mA	$\text{output} = \left(\frac{\text{datatable}}{1,000} \right)$	2000-22000 (2.000-22.000mA)	1000	min=2mA max=22mA hold last=hold 50%=12mA
5	4-20mA		4-20mA	not assigned			
6	4-20mA		4-20mA	not assigned			
7	unsigned integer as 4-20mA	0.03% of 4-20mA	4-20mA	$\text{output} = 16 \left(\frac{\text{datatable}}{65,535} \right) + 4$	0-65,535 (4-20mA)	4095	min=4mA max=20mA hold last=hold 50%=12mA
8	0-20mA		0-20mA	not assigned			
9	0-20mA		0-20mA	not assigned			

Table 2.4 1797-OE8 Data Formats

Data Format	Format	Resolution	Full Output Range	Module Data Processing	Data Table Value (Interpretation)	Count per mA	Analog Fault State
10	0-20mA		0-20mA	not assigned			
11	D/A count as 0-20mA	0.28% of 0-20mA	0-22mA	$\text{output} = 22 \left(\frac{\text{datatable}}{8,000} \right)$	0-8000 (0-22mA)	363	min=0mA max=22mA hold last=hold 50%=11mA
12	4-20mA			not assigned			
13	% as 4-20mA	0.16% of 4-20mA	3-21mA	$\text{output} = 16 \left(\frac{\text{datatable}}{10,000} \right) + 4$	-625 - +10625 (2's complement) (-6.25% - +106.25%)	625	min=3mA max=21mA hold last=hold 50%=12mA
14	% as 4-20mA	0.16% of 4-20mA	2-22mA	$\text{output} = 16 \left(\frac{\text{datatable}}{10,000} \right) + 4$	-1250 - +11250 (2's complement) (-12.50% - +112.50%)	625	min=2mA max=22mA hold last=hold 50%=12mA
15	4-20mA		4-20mA	not assigned			

Fault Alarm

Fault Alarm selects whether the channel pair fault detection is enabled or disabled. There is a 100Hz (10ms) filter for wire off/lead break detection.

Use your programming software to set the Fault Alarm. Set the feature bit to 0 to disable the alarm. Set the bit to 1 to enable wire off/lead break fault detection.

Understanding Image Table Mapping and Bit/Word Descriptions

Use the table below to understand bits used in image table mapping and bit/word descriptions. Complete definitions of these features documented below can be found in Chapter 2.

Table 2.5 Bit/Word Descriptions

Bit: (s):	Location:	Definition:
Ch	1797-IE8 and -IE8NF Input and output maps 1797-OE8 Input and output maps	Channel
Ovr Alm	1797-IE8 and -IE8NF Input map	Overrange Alarm
Und Alm	1797-IE8 and -IE8NF Input map	Underrange Alarm
Rm Flt	1797-IE8 and -IE8NF Input map	Remote Fault
Lo Flt	1797-IE8 and -IE8NF Input map	Local Fault
Res Flg	1797-IE8 and -IE8NF Input map 1797-OE8 Input map	Response Flag
Out Enbl	1797-OE8 Output map	Output Enable
U/D	1797-IE8 and -IE8NF Output map	Up/down
Flt Md	1797-IE8 and -IE8NF Output map	Fault Module
Cd Flg	1797-IE8 and -IE8NF Output map 1797-OE8 Output map	Command Flag
Flt Alm	1797-OE8 Input map	Fault Alarm
Glbl Rst	1797-OE8 Output map	Global Reset
Lo Flt Md	1797-OE8 Output map	Local Fault Module
Alg Flt Ste	1797-OE8 Output map	Analog Fault State
Lth Rty	1797-OE8 Output map	Latch Retry
Dig Flt Ste	1797-OE8 Output map	Digital Fault State
Alg Dig Md	1797-OE8 Output map	Analog Digital Module
Diagnostic Status	1797-IE8 and -IE8NF Input map 1797-OE8 Input map	Diagnostic Status

Analog Input Modules (1797-IE8 and -IE8NF) Image Table Mapping

Table 2.6 Input Map (Read Words)

Bit →	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Word ↓	Read															
0	Channel 0 Input Data															
1	Channel 1 Input Data															
2	Channel 2 Input Data															
3	Channel 3 Input Data															
4	Channel 4 Input Data															
5	Channel 5 Input Data															
6	Channel 6 Input Data															
7	Channel 7 Input Data															
8	Ovr Alm ch 7	Ovr Alm ch 6	Ovr Alm ch 5	Ovr Alm ch 4	Ovr Alm ch 3	Ovr Alm ch 2	Ovr Alm ch 1	Ovr Alm ch 0	Und Alm ch 7	Und Alm ch 6	Und Alm ch 5	Und Alm ch 4	Und Alm ch 3	Und Alm ch 2	Und Alm ch 1	Und Alm ch 0
9	Rm Flt ch 7	Rm Flt ch 6	Rm Flt ch 5	Rm Flt ch 4	Rm Flt ch 3	Rm Flt ch 2	Rm Flt ch 1	Rm Flt ch 0	Lo Flt ch 7	Lo Flt ch 6	Lo Flt ch 5	Lo Flt ch 4	Lo Flt ch 3	Lo Flt ch 2	Lo Flt ch 1	Lo Flt ch 0
10													Diagnostic Status			
11	Res Flg	Module command response							Module response data							

Where: ch = channel
 Ovr Alm = Overrange Alarm
 Und Alm = Underrange Alarm
 Rm Flt = Remote Fault
 Lo Flt = Local Fault
 Res Flg = Response Flag

Table 2.7 Output Map (Write Words)

Bit →	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Word ↓	Write															
0			High and Low Error Level					U/D 0-3	Filter Cutoff 0-3			Data Format			Flt Md	
1			High and Low Error Level					U/D 0-3	Filter Cutoff 0-3			Data Format			Flt Md	
2	Cd Flg	Module command							Module command data							

Where: Out Enbl = Output Enable
 U/D = up/down
 Flt Md = Fault Module
 Cd Flg = Command Flag

Bit/Word Description for the Analog Input Modules (1797-IE8 and -IE8NF)

Table 2.8 Fault Mode - Write Words 0 and 1

Word 0	Bit 00	Fault enable for channels 0-3
Word 1	Bit 00	Fault enable for channels 4-7

Where: 0 = disabled

1 = enable with wire-off and overload or short circuit

Table 2.9 “Add-On” Filter Selections - Write Words 0 and 1

Word	Bits			Description
0	07	06	05	Channels 0-3
1	07	06	05	Channels 4-7
	0	0	0	Hardware filtering only (default filtering) ⁽¹⁾
	0	0	1	40Hz (25ms) ⁽¹⁾
	0	1	0	20Hz (50ms) ⁽¹⁾
	0	1	1	10Hz (100ms)
	1	0	0	4Hz (250ms)
	1	0	1	2Hz (500ms)
	1	1	0	1Hz (1s)
	1	1	1	0.5Hz (2s)

⁽¹⁾ 1797-IE8NF is reserved.

Table 2.10 Remote Transmitter Error Up/Down - Write Words 0 and 1

Word 0	Bit 08	Up/down channels 0-3
Word 1	Bit 08	Up/down channels 4-7

Where: 0 = remote fault is enabled by transmitter overrange

1 = remote fault is enabled by transmitter underrange

Table 2.11 Data Format - Write Words 0 and 1

	Bits				Description
Word 0	04	03	02	01	Data format for channels 0-3
Word 1	04	03	02	01	Data format for channels 4-7
	0	0	0	0	0-22mA, w/error steps (default)
	0	0	0	1	0-22mA = 0 to 110%, w/error steps
	0	0	1	0	0-22mA = 0 to 104.8%, square root, w/error steps
	0	0	1	1	0-22mA = 0 to 65,535, unsigned integer, w/error steps
	0	1	0	0	2-22mA, w/error steps
	0	1	0	1	2-22mA = -12.5% to 112.5%, w/error steps
	0	1	1	0	4-22mA = 0 to 106%, square root, w/error steps
	0	1	1	1	4-20mA = 0 to 65,535, unsigned integer, w/error steps
	1	0	0	0	Not assigned
	1	0	0	1	Not assigned
	1	0	1	0	Not assigned
	1	0	1	1	0-22mA = A/D count, w/fixed error
	1	1	0	0	3.6-21mA = NAMUR NE 43, w/fixed error
	1	1	0	1	3-21mA = -6.25 to 106.28% w/fixed error
	1	1	1	0	2-22mA = -12.5 to 112.5% w/fixed error
	1	1	1	1	Not assigned

Table 2.12 Error Level 0.1mA Steps

	Bits					Description
Word 0	13	12	11	10	9	Error level channels 0-3
Word 1	13	12	11	10	9	Error level channels 4-7
	0	0	0	0	0	Disabled
						0.1mA * step value = remote fault alarm threshold
						Examples
Data Format	0	0	1	1	1	Step value = 7, 0.1mA * 7 = 0.7mA Remote fault alarm at -4.38% or +104.38%
2-22mA -12.5 to 112.5%	0	1	1	1	1	Binary value = 15, 0.1mA * 15 = 1.5mA Remote fault alarm at -9.38% or + 109.38%

Analog Output Module (1797-OE8) Image Table Mapping

Table 2.13 Input Map (Read Words)

Bit →	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Word ↓																
0	Flt Alm ch7	Flt Alm ch6	Flt Alm ch5	Flt Alm ch4	Flt Alm ch3	Flt Alm ch2	Flt Alm ch1	Flt Alm ch0					Diagnostic Status			
1	Res Flg	MODULE Command Response							MODULE Response Data							

Where: ch = channel
 Flt Alm = Fault Alarm
 Res Flg = Response Flag

Bit/Word Descriptions for the Analog Output Module (1797-0E8)

Table 2.14 Output Map (Write Words)

Bit →	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Word ↓																
0	Out Enbl	Glbl Rst	RESERVED						Dig Out ch7	Dig Out ch6	Dig Out ch5	Dig Out ch4	Dig Out ch3	Dig Out ch2	Dig Out ch1	Dig Out ch0
1	Channel 0 Output Data															
2	Channel 1 Output Data															
3	Channel 2 Output Data															
4	Channel 3 Output Data															
5	Channel 4 Output Data															
6	Channel 5 Output Data															
7	Channel 6 Output Data															
8	Channel 7 Output Data															
9	Lo Flt Md		Flt Md ch 2-3	Flt Md ch 0-1	Alg Flt Ste ch2-3		Alg Flt Ste ch0-1		Data Format ch2-3				Data Format ch0-1			
10	Lth Rty 4-7	Lth Rty 0-3	Flt Md ch 6-7	Flt Md ch 4-5	Alg Flt Ste ch6-7		Alg Flt Ste ch4-5		Data Format ch6-7				Data Format ch4-5			
11	Dig Flt Ste ch7	Dig Flt Ste ch6	Dig Flt Ste ch5	Dig Flt Ste ch4	Dig Flt Ste ch3	Dig Flt Ste ch2	Dig Flt Ste ch1	Dig Flt Ste ch0	Alg Dig Md ch7	Alg Dig Md ch6	Alg Dig Md ch5	Alg Dig Md ch4	Alg Dig Md ch3	Alg Dig Md ch2	Alg Dig Md ch1	Alg Dig Md ch0
12	Cd Flg	MODULE Command							MODULE Command Data							

Where:

- ch = channel
- Dig Out = Digital Output
- Lo Flt Md = Local Fault Mode
- Flt Md = Fault Mode
- Alg Flt Ste = Analog Fault State
- Lth Rty = Latch Retry
- Dig Flt Ste = Digital Fault State
- Alg Dig Md = Analog/Digital Mode
- Out Enbl = Output Enable
- Glbl Rst = Global Reset

Table 2.15 Data Format Control

Data Format				Range	Resolution	Full Range	Interpretation	Data Table Value	Count per mA
0	0	0	0	0-20mA	0.1% of 0-20mA	0-22mA	0-22mA	0-22000	1000
0	0	0	1	0-20mA	0.2% of 0-20mA	0-22mA	0-110%	0-11000	500
0	0	1	0	0-20mA		0-20mA	not assigned		
0	0	1	1	0-20mA	0.03% of 0-20mA	0-20mA	unsigned integer	0-65,535	3276
0	1	0	0	4-20mA	0.1% of 4-20mA	2-22mA	2-22mA	2000-22000	1000
0	1	0	1	4-20mA		4-20mA	not assigned		
0	1	1	0	4-20mA		4-20mA	not assigned		
0	1	1	1	4-20mA	0.03% of 4-20mA	4-20mA	unsigned integer	0-65,535	4095
1	0	0	0	0-20mA		0-20mA	not assigned		
1	0	0	1	0-20mA		0-20mA	not assigned		
1	0	1	0	0-20mA		0-20mA	not assigned		
1	0	1	1	0-20mA	0.28% of 0-20mA	0-22mA	D/A count	0-8000	363
1	1	0	0	4-20mA			not assigned		
1	1	0	1	4-20mA	0.16% of 4-20mA	3-21mA	-6.25 to +106.25%	-625 to +10625	625
1	1	1	0	4-20mA	0.16% of 4-20mA	2-22mA	-12.5 to +112.5%	-1250 to +11250	625
1	1	1	1	4-20mA		4-20mA	not assigned		

Chapter Summary

In this chapter, we told you about the FLEX Ex system and the analog I/O modules, and how they communicate with programmable controllers. Move to Chapter 3 to learn how to install your FLEX Ex analog module.

How to Install Your FLEX Ex Analog Modules

What this Chapter Contains Read this chapter to install the input and output analog modules.

For information on:	See page:
Before You Install Your Analog Module	3-1
Compliance to European Union Directives	3-2
Installation in Zone 1	3-3
Removal and Insertion Under Power	3-4
Installing the Module	3-4
Connecting Wiring to the FLEX Ex I/O Analog Modules	3-11
Grounding the Module	3-14
Chapter Summary	3-14

Before You Install Your Analog Module

Before installing your FLEX Ex analog module:

Table 3.1 Steps to Complete Before Installation

You need to:	As described under:
Verify that the module will be installed in a suitable metal enclosure	Installation in Zone 1, page 3-3
Position the keyswitch on the terminal base	Installing the Module, page 3-9

ATTENTION



These modules do not receive primary operational power from the backplane. +/-V dc power must be applied to your module before installation. If power is not applied, the module position will appear to the adapter as an empty slot in your chassis.

Compliance to European Union Directives

If these products have the CE mark they are approved for installation within the European Union and EEA regions. They have been designed and tested to meet the following directives.

EMC Directive

These products are tested to meet the Council Directive 89/336/EC Electromagnetic Compatibility (EMC) as amended by 92/31/EC and 93/68/EEC, by applying the following standards:

- EN61000-6-4:2001, Electromagnetic Compatibility (EMC) - Part 6-4: Generic Standard for Industrial Environments (Class A)
- EN61000-6-2:2001, Electromagnetic Compatibility (EMC) - Part 6-2: Generic Standards - Immunity for Industrial Environments
- EN61326-1997 + A1-A2, Electrical Equipment For Measurement, Control, and Laboratory Use - Industrial EMC Requirements

ATEX Directive

These products are tested in conjunction with associated I/O modules to meet the Council Directive 94/9/EC (ATEX) Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres by applying the following standards:

- EN50014:1997 + A1-A2, Electrical Apparatus for Potentially Explosive Atmospheres
- EN50020:1994, Electrical Apparatus for Potentially Explosive Atmospheres - Intrinsic Safety “i”
- EN50284:1999, Special Requirements for Construction, Test and Marking of Electrical Apparatus of Equipment Group II, Category 1G
- EN50281-1-1:1998 + A1, Electrical Apparatus for Use in the Presence of Combustible Dust - Part 1-1: Protection by Enclosure

Installation in Zone 1

These modules must not be exposed to the environment. Provide a suitable metal enclosure. These modules have a protection factor of IP20.

WARNING



These modules cannot be used in an intrinsically safe environment after they have been exposed to non-intrinsically safe signals.

Installation in Zone 22

When the module is installed in Zone 22, the following cabinets must be used: IVK-ISRPI-V16LC; IVK-ISRPI-V8HYW; or IVK-ISRPI-V8LC. These cabinets can be purchased from:

Pepperl+Fuchs GmbH
Königsberger Allee 85-87, D-68307
Mannheim, Germany
Attn: PA Sales Dept.
Kirsten Becker
Telephone +49 776 1298
www.pepperl-fuchs.com

The IS-RPI cabinets (type IVK2-ISRPI-V8LC, IVK2-ISRPI-V8HYW, or IVK-ISRPI-V16LC) ensures the basic protection for the intrinsically safe apparatus of the IS-RPI system for use in Zone 22. It corresponds with category 3D according to RL 94/9 EG and with the type label marked with the following information:

Pepperl+Fuchs GmbH
68301 Mannheim
IVK2-ISRPI-V8LC (or IVK2-ISRPI-V8HYW or IVK-ISRPI-V16LC)
Ⓔ II 3D IP54 T 70°C
CE
Serial (manufacturing) number
Model

Electrostatic Charge

Protect the system against electrostatic charge. Post a sign near this module: **Attention! Avoid electrostatic charge.** For your convenience, a sign which can be cut out and posted is included in this user manual before the back cover.

Removal and Insertion Under Power

WARNING



These module are designed so you can remove and insert them under power. However, take special care when removing or inserting these modules in an active process. I/O attached to any module being removed or inserted can change states due to its input/output signal changing conditions.

If you insert or remove the terminal base while backplane power is on, an electrical arc can occur. This could cause an explosion in hazardous location installations.

Be sure that power is removed or the area is nonhazardous before proceeding.

Installing the Module

Installation of the analog module consists of:

- mounting the terminal base unit
- installing the analog I/O module into the terminal base unit
- installing the connecting wiring to the terminal base unit

If you are installing your module into a terminal base unit that is already installed, proceed to “Mounting the Analog Modules on the Terminal Base” on page 9.

ATTENTION



Make certain that you power this terminal base module combination with an intrinsically safe power supply. Do not exceed the values listed in the specifications for the terminal base or module.

Do not use the unused terminals on the terminal base unit. Using the terminals as supporting terminals can result in damage to modules and/or unintended operation of your system.


Mounting on a DIN Rail


ATTENTION



Do not remove or replace a terminal base unit when power is applied. Interruption of the flexbus can result in unintended operation or machine motion.

1. Remove the cover plug in the male connector of the unit to which you are connecting this terminal base unit.
2. Check to make sure that the 16 pins in the male connector on the adjacent device are straight and in line so that the mating female connector on this terminal base unit will mate correctly.
3. Make certain that the female flexbus connector is **fully retracted** into the base unit.
4. Position the terminal base over the 35 x 7.5mm DIN rail **A** (A-B pt. no. 199-DR1).






Slide the terminal base over tight against the adapter (or preceding terminal base). Make sure the hook on the terminal base slides under the edge of the adapter (or preceding terminal base) and the flexbus connector is fully retracted.

ATTENTION




Do not force the terminal base into the adjacent modules. Forcing the units together can bend or break the hook and allow the units to separate and break communication over the backplane.

5. Rotate the terminal base onto the DIN rail with the top of the rail hooked under the lip on the rear of the terminal base. **Use caution to make sure that the female flexbus connector does not strike any of the pins in the mating male connector.**



Press down on the terminal base unit to lock the terminal base on the DIN rail. If the terminal base does not lock into place, use a screwdriver or similar device to open the locking tab, press down on the terminal base until flush with the DIN rail and release the locking tab to lock the base in place.



Gently push the flexbus connector into the side of the adapter (or preceding terminal base) to complete the backplane connection.

6. For specific wiring information, refer to the installation instructions for the module you are installing in this terminal base unit. Terminal assignments are also given later in this chapter, see page 3-11.
7. Repeat the above steps to install the next terminal base.
8. Be sure the flexbus connector cover on the last terminal base is in place.


Panel/Wall Mounting

Installation on a wall or panel consists of:

- laying out the drilling points on the wall or panel
- drilling the pilot holes for the mounting screws
- mounting the adapter mounting plate
- installing the terminal base units and securing them to the wall or panel

If you are installing your module into a terminal base unit that is already installed, proceed to Mounting the Analog Modules on the Terminal Base Unit on page 3-9.


Use the mounting kit Cat. No. 1794-NM1 for panel/wall mounting.



To install the mounting plate on a wall or panel:

1. Lay out the required points on the wall/panel as shown in the drilling dimension drawing.

Drilling Dimensions for Panel/Wall Mounting of FLEX Ex I/O




Inches
(Millimeters)



ATTENTION: Be careful of metal chips when drilling cable mounting holes. Do not drill holes above a system that has any modules installed.

Cable length approximately 11.5 (292.1) or 35.5 (901.0) from upper connector [length depends upon cable - 1ft (0.3m) or 3ft (0.091m)]



40871

2. Drill the necessary holes for the #6 self-tapping mounting screws.
3. Mount the mounting plate (1) for the adapter module using two #6 self-tapping screws (18 included for mounting up to 8 modules and the adapter).

IMPORTANT

Make certain that the mounting plate is properly grounded to the panel. Refer to "Industrial Automation Wiring and Grounding Guidelines," publication 1770-4.1.


4. Hold the adapter (2) at a slight angle and engage the top of the mounting plate in the indentation on the rear of the adapter module.
5. Press the adapter down flush with the panel until the locking lever locks.

6. Position the terminal base unit up against the adapter and push the female bus connector into the adapter.
7. Secure to the wall with two #6 self-tapping screws.
8. Repeat for each remaining terminal base unit.

Mounting the Analog Modules on the Terminal Base Unit


The analog input and output modules mount on a 1797-TB3 or TB3S intrinsically safe terminal base unit.

1. Rotate keyswitch (1) on terminal base unit (2) clockwise to position 3 for the 1797-IE8 or -IE8NF or position 4 for the 1797-OE8 as required for each type of module. **Do not change the position of the keyswitch after wiring the terminal base unit.**



2. Make certain the flexbus connector (3) is pushed all the way to the left to connect with the neighboring terminal base/adapter. You cannot install the module unless the connector is fully extended.

3. Make sure the pins on the bottom of the module are straight so they will align properly with the connector in the terminal base unit.
4. Position the module (4) with its alignment bar (5) aligned with the groove (6) on the terminal base.
5. Press firmly and evenly to seat the module in the terminal base unit. The module is seated when the latching mechanism (7) is locked into the module.
6. Make certain that you only connect terminal base units to other intrinsically safe system modules or adapters to maintain the integrity of the intrinsically-safe backplane.
7. Remove cap plug (8) and attach another intrinsically safe terminal base unit to the right of this terminal base unit if required. Make sure the last terminal base has the cap plug (8) in place.



41307

The adapter is capable of addressing eight modules. Do not exceed a maximum of eight terminal base units in your system.

Wiring the Terminal Base Units

Wiring the FLEX Ex I/O analog modules is done through the 1797-TB3 and 1797-TB3S terminal base units.

ATTENTION



The FLEX Ex analog I/O modules do not receive primary operational power from the backplane. +/-V dc power must be applied to your module before operation. If power is not applied, the module position will appear to the adapter as an empty slot in your chassis. If the adapter does not recognize your module after installation is completed, cycle power to the adapter.

Make certain that you power these modules with an intrinsically safe power supply. Do not exceed the values listed in the specifications for the modules.

Connecting Wiring to the FLEX Ex I/O Analog Modules

Inputs/Outputs

Each 1797-IE8 or -IE8NF input can be operated from an analog field device signal, and each 1797-OE8 output channel can operate an analog field device. **Do not apply any non-intrinsically safe signals to these modules.**

IMPORTANT


When using an intrinsically safe electrical apparatus according to EN50020, the European Community directives and regulations must be followed.

The channels of the 1797-IE8 and -IE8NF are electrically connected to each other and have a common plus-line. The channels of the 1797-OE8 are electrically connected to each other.

IMPORTANT

When interconnecting several lines, you must consider the total accumulated power and check for intrinsic safety.

Connections for the 1797-IE8 and -IE8NF Modules



For Two-Wire Transmitter Devices

1. Connect the individual input wiring to (+) terminals (0, 4, 8, 12) on the 0-15 row (A) and on the 16-33 row (B) (terminals 17, 21, 25, 29) as indicated in the table below.
2. Connect the associated input to the corresponding (sig) terminal (1, 5, 9, 13) on the 0-15 row (A), and on the 16-33 row (B) (terminals 18, 22, 26, 30) for each input as indicated in the table below.
3. Connect +V dc power to terminal 34 on the 34-51 row (C).
4. Connect -V to terminal 35 on the 34-51 row (C).
5. If continuing power to the next terminal base unit, connect a jumper from terminal 50 (+V) on this base unit to terminal 34 on the next base unit.
6. If continuing common to the next terminal base unit, connect a jumper from terminal 50 (-V) on this base unit to terminal 35 on the next base unit.

Table 3.2 Wiring connections for the 1797-IE8 and -IE8NF Modules

Input	Input Source	Input Signal	Input Return	Input	Input Source	Input Signal	Input Return
Input 0	A-0	A-1	A-2	Input 4	B-17	B-18	B-19
Input 1	A-4	A-5	A-6	Input 5	B-21	B-22	B-23
Input 2	A-8	A-9	A-10	Input 6	B-25	B-26	B-27
Input 3	A-12	A-13	A-14	Input 7	B-29	B-30	B-31
+V	Terminals 34 and 50						
-V	Terminals 35 and 51						


Terminals 16, 33, 40, 41, 42, 43, 44 and 45 are connected to chassis ground.

ATTENTION




Do not use the unused terminals on the terminal base unit. Using these terminals as supporting terminals can result in damage to the module and/or unintended operation of your system.

Connections for the 1797-OE8 Module



1797-OE8 Module



No connections allowed to terminals 2, 3, 6, 7, 10, 11, 14, 15, 19, 20, 23, 24, 27, 28, 31, 32, 36, 37, 38, 39, 46, 47, 48, 49

1. Connect the individual output wiring to (+) terminals (0, 4, 8, 12) on the 0-15 row (A) and on the 16-33 row (B) (terminals 17, 21, 25, 29) as indicated in the table below.
2. Connect the associated output to the corresponding (-) terminal (1, 5, 9, 13) on the 0-15 row (A), and on the 16-33 row (B) (terminals 18, 22, 26, 30) for each input as indicated in the following table.
3. Connect +V dc power to terminal 34 on the 34-51 row (C).
4. Connect -V to terminal 35 on the 34-51 row (C).
5. If continuing power to the next terminal base unit, connect a jumper from terminal 50 (+V) on this base unit to terminal 34 on the next base unit.
6. If continuing common to the next terminal base unit, connect a jumper from terminal 51 (-V) on this base unit to terminal 35 on the next base unit.

Table 3.3 Wiring connections for the 1797-OE8 Module

Output	Output +	Output –	Output	Output +	Output –
Output 0	A-0	A-1	Output 4	B-17	B-18
Output 1	A-4	A-5	Output 5	B-21	B-22
Output 2	A-8	A-9	Output 6	B-25	B-26
Output 3	A-12	A-13	Output 7	B-29	B-30
+V	Terminals 34 and 50				
-V	Terminals 35 and 51				


Terminals 16, 33, 40, 41, 42, 43, 44 and 45 are connected to chassis ground.

ATTENTION

Do not use the unused terminals on the terminal base unit. Using these terminals as supporting terminals can result in damage to the module and/or unintended operation of your system.

Grounding the Module

All I/O wiring must use shielded wire. Shields must be terminated external to the module, such as bus bars and shield-terminating feed throughs.



30820

Chapter Summary

In this chapter, we told you how to install your input module in an existing programmable controller system and how to wire to the terminal base units.

Move to chapter 4 to learn about input, output and configuration files for the analog I/O modules on ControlNet.

Input, Output, and Configuration Files for the Analog I/O Modules on the ControlNet Network

What this Chapter Contains

Read this chapter to familiarize yourself with input, output and configuration files for analog I/O modules on ControlNet.

For information on:	See page:
Using Programming Software in Your FLEX Ex Application	4-2
About the ControlNet Ex Adapter	4-2
Communication Over the FLEX Ex Backplane	4-3
I/O Structure	4-4
Fault State Data	4-6
Device Actions	4-6
Chapter Summary	4-8

In this chapter, you will learn about:

- using software to configure the FLEX Ex I/O modules
- ControlNet Ex Adapter
- I/O structure
- fault state data
- communication fault data
- idle state behavior
- input data behavior upon module removal

This chapter provides a brief description of the steps you must take in your programming software to configure FLEX Ex I/O modules and an overview of what occurs during configuration.

For a full explanation of how to use your programming software to perform module configuration, use the software online help.

Using Programming Software in Your FLEX Ex Application

When using FLEX Ex I/O analog modules, you must perform I/O mapping and configure the ControlNet network before generating configuration data for your I/O modules.

For example, you may use **RSNetWorx™** to connect FLEX Ex I/O modules to a ControlNet processor or scanner through a FLEX Ex ControlNet Ex adapter (cat. no. 1797-ACNR15). The I/O configuration portion of another programming software, for example **RSLogix5™** could be used to generate the configuration data for each I/O module in the control system.

Configuration data is transferred from the controller to the I/O modules when communication to the modules is first established.

Follow these general guidelines when configuring I/O modules:

1. Perform I/O mapping.
2. Configure all I/O modules.
3. Change to Run mode to initiate communication and download
4. module configuration.


About the ControlNet Ex Adapter

The FLEX Ex ControlNet Ex adapter interfaces up to 8 FLEX Ex modules to a ControlNet processor or scanner. The adapter can support ControlNet real-time data connections to individual modules or module groups. Each connection is independent of the others and can be from different processors or scanners.

Communication Over the FLEX Ex Backplane

One 1797-ACNR15/B ControlNet Ex adapter can interface up to eight terminal base units with installed FLEX Ex modules, forming a FLEX Ex system of up to eight slots.

The adapter communicates to other network system components (typically one or more controllers or scanners, and/or programming terminals) over the ControlNet network. The adapter communicates with its I/O modules over the FLEX Ex backplane.



Configuration data is not continuously updated to the module.

Scheduled Data-Transfer

Scheduled data transfer:

- is continuous.
- is asynchronous to the controller program scan.
- occurs at the actual rate displayed in the Actual Packet Interval field on the programming software ControlNet I/O mapping (monitor) screen

Unscheduled Data-Transfer

Unscheduled operations include:

- unscheduled non-discrete I/O data transfers—through ControlNet I/O Transfer (CIO) instructions
- peer-to-peer messaging—through message (MSG) instructions
- messaging from programming devices

Unscheduled messaging on a ControlNet network is non-deterministic. Your application and your configuration—number of nodes, application program, NUT, amount of scheduled bandwidth used, etc.—determine how much time there is for unscheduled messaging.

Module I/O Mapping


The I/O map for a module is divided into read words and write words. Read words consist of **input and status words**, and write words consist of **output and configuration words**. The number of read words or write words can be 0 or more.

The length of each I/O module's read words and write words vary in size depending on module complexity. Each I/O module will support at least 1 input word or 1 output word. Status and configuration are optional, depending on the module.

I/O Structure

Output data is received by the adapter in the order of the installed I/O modules. The output data for slot 0 is received first, followed by the output data for slot 1, and so on up to slot 7.

The first word of input data sent by the adapter is the Adapter status word. This is followed by the input data from each slot, in the order of the installed I/O modules. The input data from slot 0 is first after the status word, followed by input data from slot 1, and so on up to slot 7.



41628

Adapter Status Word


The status word consists of:

- I/O module fault bits – 1 status bit for each slot

Additionally, in the case of a PLC-5 controller, it adds:

- node address changed – 1 bit (created by PLC-5 controller)
- I/O status – 1 bit (created by PLC-5 controller)

The following FLEX Ex adapter status word for a PLC-5 controller results.



As an example, in a PLC-5 system, the adapter status word bit descriptions are shown in the following table.

Table 4.1 Adapter Status Word Bit Descriptions

Bit Description:	Bit:	Explanation:
I/O Module Fault	0	This bit is set (1) when an error is detected in slot position 0.
	1	This bit is set (1) when an error is detected in slot position 1.
	2	This bit is set (1) when an error is detected in slot position 2.
	3	This bit is set (1) when an error is detected in slot position 3.
	4	This bit is set (1) when an error is detected in slot position 4.
	5	This bit is set (1) when an error is detected in slot position 5.
	6	This bit is set (1) when an error is detected in slot position 6.
	7	This bit is set (1) when an error is detected in slot position 7.
Node Address Changed (Created by PLC-5 controller.)	8	This bit is set (1) when the node address switch setting has been changed since power-up.
I/O State (Created by PLC-5 controller.)	9	Bit = 0 -idle bit = 1 - run
	10 though 15	Not used – set to 0

Possible causes for an **I/O Module Fault** are:

- transmission errors on the FLEX Ex backplane
- a failed module
- a module removed from its terminal base
- incorrect module inserted in a slot position
- the slot is empty
- the slot contains a non-discrete module

Fault State Data

The ControlNet Ex adapter provides storage for alternate module output data during communication faults or processor idle state. This “fault state data” assures that a known output will be applied to the output devices during the previously mentioned modes.

The processor or scanner software must include the means to specify this fault state data for each module. If applicable, this data is sent in the configuration block, see Image Table Mapping on page 2-13.

Device Actions

Device actions include:

- communication fault behavior
- idle state behavior
- input data behavior upon module removal

Communication Fault Behavior

You can configure the adapter response to a communication fault for each I/O module in its system. Upon detection of a communication fault, the adapter can:

- leave the module output data in its last state (hold last state)
- reset the module output data to zero (reset)
- apply fault state data to the module output

IMPORTANT

If the Output Enable bit transitions from 1 to 0 (by resetting the module output data or applying fault state data), the module uses internal analog or digital fault state bits, depending on user configuration, to determine the state of the outputs.

Idle State Behavior

The ControlNet Ex adapter can detect the state of the controlling processor or scanner. Only 2 states can be detected: run mode, or program mode (idle).

When run mode is detected, the adapter copies the output data received from the processor to the corresponding module output. When program mode is detected, the adapter can be configured to:

- leave the module output data in its last state (hold last state)
- reset the module output data to zero (reset)
- apply fault state data to the module output

If the Output Enable bit transitions from 1 to 0 (by resetting the module output data or applying fault state data), the module uses internal analog or digital fault state bits, depending on user configuration, to determine the state of the outputs.

Input Data Behavior upon Module Removal

I/O module input data sent by the adapter upon module removal is configurable. The adapter can:

- reset the module input data sent by the adapter to zero (reset)
- leave the module input data sent by the adapter in the last state before module removal (hold last state)

Chapter Summary

In this chapter you learned about input, output and configuration files for the analog I/O modules on ControlNet. Move to Chapter 5 to learn how to calibrate your module.

Calibrating Your Module

What This Chapter Contains Use this chapter to calibrate the FLEX Ex analog I/O modules.

For information on:	See page:
When and How to Calibrate Your FLEX Ex Analog I/O Module	5-1
Tools and Equipment	5-2
Using Calibration Module Command Words	5-2
Calibrating the Input Modules	5-6
Calibrating the Output Modules	5-8
Chapter Summary	5-10

IMPORTANT

This chapter provides a detailed method to perform module calibration with individual commands. This discussion is only given here to explain the general process.

In practice, you must use the I/O configuration portion of your programming software to calibrate your modules. The software executes the methodology explained here.

When and How to Calibrate Your FLEX Ex Analog I/O Module

Your module is shipped to you already calibrated. If a calibration check is required, the module must be in a FLEX Ex I/O system.

Perform module calibration periodically, based on your application. Module calibration may also be required to remove module error due to aging of components in your system.

ATTENTION

Your FLEX Ex analog I/O modules are intrinsically safe equipment. This module cannot be used in intrinsically safe environment after having been exposed to non-intrinsically safe signals.

Use one of the following general methods to calibrate your module:

- Use intrinsically safe equipment to calibrate the module.
- Use factory trained personnel under controlled conditions to calibrate the modules with non-intrinsically safe equipment to maintain your module's intrinsic safety certification.

ATTENTION


With the second method, extreme care must be exercised by the calibration personnel to avoid compromising the intrinsically safe characteristics or your modules. This method may never be used in a hazardous environment.

Tools and Equipment

To calibrate your analog I/O modules, you will need the following tools and equipment:

Table 5.1 Tools for Calibration

Tool or Equipment:	Description:	
Precision Current Source	0-22mA, 0.01µA resolution	Used for input modules
Precision Current Meter	0-22mA, 0.01µA resolution	Used for output modules
Industrial Terminal and Interconnect Cable	Programming terminal for A-B family processors	

Using Calibration Module Command Words

Module calibration is supported by Module Command words. See your module data tables in Chapter 3 to determine which words are the Module Command words. They are always the last read word and last write word. The Module Command word is broken into two parts the upper byte is the command and the lower byte is the data.

A CIO is used to structure a calibration command and submit it to the network. This includes the command and any data.

Table 5.2 MODULE Command Word

R/W	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Write	cmd flag	MODULE calibration command							MODULE calibration command data							

Typical MODULE Calibration Command Word

The controller sends a MODULE calibration command word over the network, onto the flexbus and to the module.

Table 5.3 Calibration Command Word

R/W	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
write	cmd flag	Calibration All Channels							sub-Command 0-255							
write	cmd flag	Calibration By Channel							Channel Select 0-15				sub-Command 0-15			

The I/O module may do a number of things based on the particular calibration command data sent by the controller. The table below shows the general structure of calibration commands.

The calibration command structure instructs the module to calibrate individual channels or to calibrate all channels at once. If all channels are to be calibrated at once, a single calibration command is sent along with calibration command data selecting the calibration type to be accomplished. If individual channels are to be calibrated, again, a single calibration command is sent. The calibration command data specifies the specific channel and calibration type to be accomplished.

Table 5.4 General Calibration Command Structure

MODULE Calibration Command		MODULE Calibration Command Data		
Command	Meaning	Data (up nibble)	Data (low nibble)	Meaning
		channel	command	
0	Commands Idle	x	x	command method is idle
1	No Operation	x	x	no operation is required
4	General Calibration by Channel	0-7	0	zero min and max scale coefficients
		0-7	1-15	not used
		8-15	0-15	not used
5	Min Scale Calibration by Channel	0-7	0	input = 1mA
		0-7	1-15	not used
		8-15	0-15	not used
6	Max Scale Calibration by Channel	0-7	0	input = 21mA
		0-7	1-15	not used
		8-15	0-15	not used

Table 5.4 General Calibration Command Structure

36	Calibration all Channels			
	General Calibration all Channels	0	0	zero min scale and max scale coefficients
		0	1-15	not used
	Min Scale Calibration all Channels	1	0	input = 1mA
		1	1-15	not used
	Max Scale Calibration all Channels	2	0	input = 21mA
		2	1-15	not used
		3-15	0-15	not used

For example, based on the table below, command 4 0 0 asks for zeroing the min and max coefficients of channel 0. All results are complete with this one command.

Table 5.5 Example MODULE Calibration Commands and Data

R/W	Bit															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Read	cmd flag	MODULE command response							MODULE response data							

Once the slave completes the calibration command, the module echoes back the command and data in the MODULE response word, see the General MODULE Response Word below. The controller is informed the calibration sequence is complete.

General MODULE Response Word

Once the I/O module echoes the command and data it will not treat the continued presence of the same calibration command as a signal to perform that command again. If the user wants to perform the same calibration again, a “No Operation” command must be sent from the controller to the module first.

The following tables show typical command sequences.

Table 5.6 Typical All Channels Calibration Command Sequence

Host Command Sequence									
command number	MODULE command	MODULE data							
		7	6	5	4	3	2	1	0
36	calib all chls, zero min & max	0						0	
36	calib all chls, min scale	1						0	
36	calib all chls, max scale	2						0	
0	Commands idle	0						0	

Slave Command Sequence									
command number	MODULE command response	MODULE response data							
		7	6	5	4	3	2	1	0
36	calib all chls, zero min & max	0						0	
36	calib all chls, min scale	1						0	
36	calib all chls, max scale	2						0	
0	Commands idle	0						0	

Table 5.7 Typical Channel by Channel Calibration Command Sequence

Host Command Sequence									
command number	MODULE command	MODULE data							
		7	6	5	4	3	2	1	0
4	calib ch0, zero min & max	0						0	
4	calib ch1, zero min & max	1						0	
5	calib ch0, min scale	0						0	
5	calib ch1, min scale	1						0	
6	calib ch0, max scale	0						0	
6	calib ch1, max scale	1						0	
0	Commands idle	0						0	


Slave Command Sequence									
command number	MODULE command response	MODULE response data							
		7	6	5	4	3	2	1	0
4	calib ch0, zero min & max	0						0	
4	calib ch1, zero min & max	1						0	
5	calib ch0, min scale	0						0	
5	calib ch1, min scale	1						0	
6	calib ch0, max scale	0						0	
6	calib ch1, max scale	1						0	
0	Commands idle	0						0	

Calibrating the Input Modules


To calibrate the 1797-IE8 or -IE8NF module use the following steps:

1. Attach the precision current source(s) to the module.

**Precision
Current
Sources**



**Precision
Current
Sources**



2. Send a message to the module instructing it to perform **Zero Min and Max Scale Coefficients**.
3. Await an echo message from the module announcing that it has performed **Zero Min and Max Scale Coefficients**.
4. Apply 1mA, (minimum scale calibration input(s),) to the module.
5. Send a message to the module instructing it to perform **Min Scale Calibration**.
6. Await an echo message from the module announcing that it has performed **Min Scale Calibration**.
7. Apply 21mA, (maximum scale calibration input(s),) to the module.
8. Send a message to the module instructing it to perform **Max Scale Calibration**.

9. Await an echo message from the module announcing that it has performed **Max Scale Calibration**.
10. After all channels are calibrated, send a message to the module instructing it to go to **Commands Idle** state.

The following table shows the calibration MODULE command definitions.

Table 5.8 MODULE Command Definitions


MODULE Calibration Command		MODULE Calibration Command Data		
Command	Meaning	Data (up nibble)	Data (low nibble)	Meaning
		channel	command	
0	Commands Idle	x	x	command method is idle
1	No Operation	x	x	no operation is required
4	General Calibration by Channel	0-7	0	zero min and max scale coefficients
		0-7	1-15	not used
		8-15	0-15	not used
5	Min Scale Calibration by Channel	0-7	0	input = 1mA
		0-7	1-15	not used
		8-15	0-15	not used
6	Max Scale Calibration by Channel	0-7	0	input = 21mA
		0-7	1-15	not used
		8-15	0-15	not used
36	Calibration all Channels			
	General Calibration all Channels	0	0	zero min scale and max scale coefficients
		0	1-15	not used
	Min Scale Calibration all Channels	1	0	input = 1mA
		1	1-15	not used
	Max Scale Calibration all Channels	2	0	input = 21mA
		2	1-15	not used
		3-15	0-15	not used

Calibrating the Output Modules


To calibrate the 1797-OE8 module use the following general method:

1. Attach the precision current meters(s) to the module.

Precision
Current
Sources



Precision
Current
Sources



41660

2. Send a message to the module to set its Output Enable bit to 1. This enables its outputs.
3. Send a message to the module instructing it perform **Zero Min and Max Scale Coefficients**.
4. Await an echo message from the module announcing that it has performed **Zero Min and Max Scale Coefficients**.
5. Send a message to the module instructing it to perform **Min Scale Calibration** (1mA) on the channel(s).
6. Await an echo message from the module announcing that it has performed **Min Scale Calibration**.

7. Record the value indicated by the channel(s) precision current meter into the appropriate channel's(s') data table location.
8. Send a message to the module instructing it to **Accept Value in Channel Data Word as Min Scale Calibration** on the channel(s).
9. Await an echo message from the module announcing that it has performed **Accept Value in Channel(s) Data Word(s) as Min Scale Calibration** on the channel(s).
10. Send a message to the module instructing it to perform **Max Scale Calibration** (21mA) on the channel(s).
11. Await an echo message from the module announcing that it has performed **Max Scale Calibration**.
12. Record the value indicated by the channel(s) precision current meter into the appropriate channel's(s') data table location.
13. Send a message to the module instructing it to **Accept Value in Channel(s) Data Word(s) as Max Scale Calibration** on the channel(s).
14. Await an echo message from the module announcing that it has performed **Accept Value in Channel(s) Data Word(s) as Max Scale Calibration** on the channel(s).
15. After all channels are calibrated, send a message to the module instructing it to go to **Commands Idle** state.

The following table shows the calibration MODULE command definitions.

Table 5.9 Calibration MODULE Command Definitions

MODULE Calibration Command		MODULE Calibration Command Data		
Command	Meaning	Data (up nibble)	Data (low nibble)	Meaning
		channel	command	
0	Commands Idle	x	x	command method is idle
1	No Operation	x	x	no operation is required
4	General Calibration by Channel	0-7	0	zero min scale and max scale coefficients
		0-7	1-15	not used
		8-15	0-15	not used
5	Min Scale Calibration by Channel	0-7	0	output = 1mA
		0-7	1	accept value in channel data word as min scale calibration
		0-7	2-15	not used
		8-15	0-15	not used
6	Max Scale Calibration by Channel	0-7	0	output = 21mA
		0-7	1	accept value in channel data word as max scale calibration
		0-7	2-15	not used
		8-15	0-15	not used
36	Calibration all Channels			
	General Calibration all Channels	0	0	zero min scale and max scale coefficients
		0	1-15	not used
	Min Scale Calibration all Channels	1	0	output = 1mA
		1	1	accept values in channel data words as min scale calibration
		1	2-15	not used
	Max Scale Calibration all Channels	2	0	output = 21mA
		2	1	accept values in channel data words as max scale calibration
		2	2-15	not used
		3-15	0-15	not used

Chapter Summary

In this chapter, you learned how to calibrate your FLEX Ex analog I/O modules. Move to Chapter 6 to see how to apply FLEX Ex analog I/O modules.

Applying FLEX Ex Analog I/O Modules

What this Chapter Contains

Read this chapter to learn how to use entity parameters when electrically interconnecting your FLEX Ex analog I/O module in a hazardous area.

For information on:	See page:
Evaluate the Application	6-1
Define the Area Classification	6-2
Select Protection Method(s)	6-3
Match Field Devices and I/O Modules	6-3
Optimize Power Distribution	6-7
Chapter Summary	6-9

The FLEX Ex system is different from traditional control systems used the intrinsic safety in its ability to be located directly in hazardous areas and to embrace high speed network-based control.

Evaluate the Application

Follow these steps when designing a FLEX Ex system for your application:

1. Define the area classification.
2. Select protection method(s).
3. Match field devices and I/O modules.
4. Optimize power distribution.
5. Layout the ControlNet Ex network.

An explanation of each of these steps is provided in this chapter.

Define the Area Classification

Before you can determine what components will make up your FLEX Ex system, you must define the area in which that system will operate. You must determine the following:

- classification method
- hazard
- temperature rating

Decide Classification Method

Your application location will usually decide whether the classification method is Zone or Class/Division, but the system designer may make this determination. **FLEX Ex is certified for Zone method only.** Certification is pending for Division method.

Determine Hazard

Hazard—typically gas, dust, or fibers—is determined by the material being processed. For example, a coal mine will generally be rated for dust and methane gas hazards. **FLEX Ex is certified for gas hazard only.** Certification is pending for attaching wiring to FLEX Ex I/O modules from a dust and fiber hazardous area.

Determine Temperature Rating

The spontaneous ignition temperature of the hazard in your application determines the temperature rating. For example, an application with a hydrogen hazard may use equipment with a temperature rating of T1 because hydrogen's ignition temperature is 550°C. **FLEX Ex is certified as a T4 system.**

Select Protection Method(s)

Although the FLEX Ex system primarily uses the Intrinsic Safety protection method, the system uses all methods listed below.

Table 6.1 Protection Methods for Hazardous Applications

Protection Method	Designation ¹	Method of Achieving Protection
Intrinsic Safety	EEx _{ia} /EEx _{ib}	Energy Limiting
Encapsulation	EEx _m	Segregation
Increased Safety	EEx _e	Refined Mechanical Design
Flameproof	EEx _d	Containment

¹ In the Non-Incendive protection method, n: used locally in the United States and United Kingdom.
In the Intrinsic Safety method, ia: Zone 0, 1, 2 & ib: Zone 1, 2

IMPORTANT

As not all protection methods are applicable for all locations, consult local certifying agencies to determine acceptable protection methods for your application.


Match Field Devices and I/O Modules

You must match field devices and I/O modules for your application to function properly. Consider the following:

- Verify field device and I/O module operational characteristics
- Match entity parameters of field devices and I/O modules

P/I Analog Transmitter Functional and IS Parameters

The figure below shows a typical pressure to current analog transmitter. Two types of characteristics are shown, functional and IS.




4-20mA IS
P/I Transmitter
10.5-42V operate
EEx ia IIC T4
Ui=30V
Ii=165mA
Ci=22.5nF
Li=730uH

41662

1797-IE8 and -IE8NF Functional and IS Parameters

The figure below provides data, on the Flex Ex analog input modules, which can be matched to this transmitter.



Analog Input
 $V > 17V$ at $I = 0mA$
 $V > 15.5$ at $I = 20mA$
 $V > 15V$ at $I = 22mA$
 0-22mA Measurement Range
 EEx ia/ib IIB/IIC T4
 $U_0 < 23.7V$
 $I_0 < 92.5mA$


IIB	IIC
Ca=560nF	Ca=66nF
La=10mH	La=2.5mH

41662

Loop Functionality Verification

The functional characteristics will be checked first. The figure below shows the general situation which must be analyzed for proper loop function.

On the left are the module components of the voltage source to run the loop and its internal source resistance. In the center is the cable. It represents a loss with regard to its resistance. Cable resistance is a function of cable length. On the right is the transmitter, which has a minimum voltage it must see to function properly.



41664

The loop must function properly under maximum signal current conditions, in this case 22mA. As can be seen the key variable, which must be determined, is the total loop resistance. This may be determined with the following equation:

$$R_{total} = \frac{(17-10.5)}{0.022} = 295\Omega$$

Once R_{total} is known, you must determine the actual cable resistance that can be accommodated. This is the difference between R_{total} and the module internal source and sense resistances: $R_{cable} = 295 - 91 - 22 = 182\Omega$

R_{cable} is used to determine the wiring length allowed between the module and the transmitter:


$$Cable_length = \frac{182}{2 * 0.1} = 910m$$

Note, the “2” in the denominator of the equation is necessary to account for the resistance of both cable conductors (signal source “+” and signal and return “sig”).

Intrinsic Safety Entity Verification

Next we must determine if the pressure to current analog transmitter and the Flex Ex analog input module are compatible from an IS perspective. We will make this determination for a IIC gas application.

The figure below shows an extraction of pertinent information from the figures on pages 6-3.



In the figure above, three key items are shown, the field device the interconnecting cabling and the Flex Ex module (in this example, a 1797-IE8). The entity verification is done for the gas group IIC. As the table shows, the module's entity parameters are compared to the combination of the transmitter and the wiring entity parameters.

The module's entity parameters are shown in the Module column on the left. They must be compared with the parameters shown in the Total Loop column, in the manner shown. The values in the Total Loop column are determined in the following manner:

- Total Loop $U_i =$ Transmitter U_i
- Total Loop $I_i =$ Transmitter I_i
- Total Loop $C_i = ($ Transmitter $C_i +$ Cabling C_i per length $) \times$ (cable length)
- Total Loop $L_i = ($ Transmitter $L_i +$ Cabling L_i per length $) \times$ (cable length)

As long as the Module and Total Loop entity parameters satisfy the inequalities shown the loop is acceptable for use in the hazardous environment.

I/O

The input and output modules comply fully to and provide simple entity parameters. These modules can directly interface with a wide variety of intrinsically safe controls and instrumentation. Because all field device power is supplied directly from the I/O module, no extra wiring or power sources are needed in a hazardous area.


Finally, these modules maintain intrinsic safety in hazardous areas by providing isolation from other modules in the system as well as intrinsic safety segregation between channels on the same module.

Optimize Power Distribution

Your FLEX Ex system must use adequate power supplies to support the physical locations determined earlier in this chapter. Each FLEX Ex I/O module in the system is rated for input power, and the FLEX Ex power supply is rated in the number of output channels and power available from each channel.


Assigning Power Supplies

Note the amount of power each module requires and assign it to a power supply output. Continue to assign modules to the power supply output until the supply’s output power rating is consumed. The graphic below shows the number of modules per power supply output.



Each power supply output in the FLEX Ex system is rated for 8.5W. Modules can be attached to the output until their combined power equals that number. Do not exceed the power supply maximum of 8.5W.

Assign the next module to another output as before. When all four power supply outputs are utilized, add another power supply to the system, see the figure below.

**ATTENTION**

Power supply outputs can never be paralleled. Paralleling outputs voids all intrinsic safety certifications.

Power Supply Considerations

When applying power, consider the certain characteristics of the wire connecting the power supply output to a module's power input. The wire cannot exhibit more than:

- 0.1Ω of resistance (+V and -V combined)
- 800nF of capacitance
- 10 μ F of inductance

Typically, these restrictions will yield wiring lengths of not more than 3.5m or 5.8m (1.5mm² and 2.5mm² wire respectively) without the use of special wiring or wiring methods.

Chapter Summary

In this chapter you learned how to apply the FLEX Ex analog I/O modules. Move to Chapter 7 to learn about troubleshooting your modules.

Notes:

Troubleshooting the FLEX Ex Analog I/O Modules


What this Chapter Contains Read this chapter to troubleshoot your I/O module.

For information on:	See page:
Status Indicators	7-1
Repair	7-2
Chapter Summary	7-2

Status Indicators

1797-IE8 and -IE8NF Modules

The 1797-IE8 and -IE8NF modules have one power indicator that is on when power is applied to the module and one status indicator for each input.



A = Status indicators


B = Insertable labels for writing individual input designations

C = Power indicator

Indicator	Color	State	Meaning
Status	Red	On	At power up – Channel 0 indicator lights at powerup until all internal diagnostics are checked. After successful powerup, the indicator goes off if no fault is present. After successful powerup – Indicates a critical fault (diagnostic failure, etc.)
		Blinking (when faults are enabled, and bit set)	Indicates a noncritical channel fault
Power		Off	Module not powered
	Green	On	Module receiving power

1797-OE8 Module

The 1797-OE8 module has one power that is on when power is applied to the module and one status indicator for each input.



- A = Status indicators
- B = Insertable labels for writing individual input designations
- C = Power indicator

Indicator	Color	State	Meaning
Status	Red	On	At power up – Channel 0 indicator lights at powerup until all internal diagnostics are checked. After successful powerup, the indicator goes off if no fault is present. After successful powerup – Indicates a critical fault (diagnostic failure, etc.)
		Blinking (when faults are enabled, and bit set)	Indicates a noncritical channel fault
Power		Off	Module not powered
	Green	On	Module receiving power

Repair

This module is not field repairable. Any attempt to open this module will void the warranty and IS certification. If repair is necessary, return this module to the factory.

Chapter Summary

In this chapter you learned how to troubleshoot the FLEX Ex analog I/O modules. Move to Appendix A to see the specifications for your module.




Notes:

Specifications

1797-IE8 and -IE8NF Input Modules

Specifications

Number of Inputs	8 single-ended, non-isolated
IS Input Type	EEx ia IIB/IIC T4 AEx ia IIC T4 Class I, II, III Division 1 Groups A-G T4 (1797-IE8) Class I, II, III Division 1 & 2 Groups A-G T4 (1797-IE8NF)
IS Module Type	EEx ib IIB/IIC T4 AEx ib IIC T4 Class I Division 1 & 2 Groups A-D T4
Resolution	16 bits
Transfer Characteristics Accuracy at 20°C (68°F) Temperature Drift	0.1% of output signal range 0.005%/C of output signal range
Functional Data Range	>15V @22mA >21.5V @ 0mA
Data Format	Configurable
Step Response to 99% of FS	4ms
Module from Adapter Best/Worst Update Time	50/1450µs
Indicators	8 red fault indicators 1 green power
Output (Intrinsically Safe) (16 pin male/female flexbus connector)	$U_i \leq 5.8V$ dc $I_i \leq 400mA$ $L_i = \text{Negligible}$ $C_i \leq 1.35\mu F$
Isolation Path Input to Power Supply Input to Flexbus Input to Input Power Supply to Flexbus	Isolation Type Galvanic to DIN EN50020 Galvanic to DIN EN50020 None Galvanic to DIN EN50020
Power Supply (+V, -V intrinsically safe)	$U_i \leq 9.5V$ dc $I_i \leq 1A$ $L_i = \text{Negligible}$ $C_i = \text{Negligible}$
Module Field-side Power Consumption	7.5W

Power Dissipation	5.2W
Thermal Dissipation	17.75 BTU/hr
Module Location	Cat. No. 1797-TB3 or -TB3S
Conductor Wire Size	12 gauge (4mm ²) stranded maximum 3/64in (1.2mm) insulation maximum
Dimensions	46mm x 94mm x 75mm (1.8in x 3.7in x 2.95in)
Weight	200g (approximately)
Keyswitch Position	3
Environmental Conditions	
Operational Temperature	-20 to +70°C (-4 to +158°F)
Storage Temperature	-40 to +85°C (-40 to +185°F)
Relative Humidity	5 to 95% noncondensing
Shock	Tested to 15g peak acceleration, 11(+1)ms pulse width
Operating Nonoperating Vibration	Tested to 15g peak acceleration, 11(+1)ms pulse width Tested 2g @ 10-500Hz per IEC68-2-6
Agency Certification	
CENELEC	II (1) 2G EEx ia/ib IIB/IIC T4 II (1D) (2D)
UL, C-UL	Class I Division 1 & 2 Groups A-D T4 Class I Zone 1 & 2 AEx ib/[ia] IIC T4
FM	Class I Division 1 Groups A-D T4 Class I Zone 1 AEx ib/[ia] IIC T4
Certificates	
CENELEC	DMT 98 ATEX E 020 X 
UL, C-UL	UL Certificate Number 99.19699 c  US Class I Division 1 Hazardous
FM	FM Certificate Number 3009806 

1797-IE8 and -IE8NF CE, CENELEC I/O Entity Parameters

Measurement input (sig to -) for ch 0 to ch 7 (terminals: 1-2; 5-6; 9-10; 13-14; 18-19; 22-23; 26-27; 30-31)

	Protection	Group	Allowed Capacitance	Allowed Inductance
$U_o = 5V$ $I_o = 1mA$ $P_o = 1.3mW$ $U_i = 28V$ $I_i = 93mA$ C_i and L_i negligible	EEx ia	IIB	1000 μ F	1H
		IIC	100 μ F	1H

Source output (+ to sig) for ch 0 to ch 7 (terminals: 0-1; 4-5; 8-9; 12-13; 17-18; 21-22; 25-26; 29-30)

	Protection	Group	Allowed Capacitance	Allowed Inductance
$U_o = 23.7V$ $I_o = 92.5mA$ $P_o = 548mW$	EEx ia	IIB	560nF	10mH
		IIC	66nF	2.5mH
If concentrated capacitance and/or inductance are available, use the following values.	EEx ia	IIB	320nF	10mH
		IIC	60nF	2mH

Source output plus measurement input (+ to -) for ch 0 to ch 7 (terminals: 0-2; 4-6; 8-10; 12-14; 17-19; 21-23; 25-27; 29-31)

	Protection	Group	Allowed Capacitance	Allowed Inductance
$U_o = 23.7V$ $I_o = 93.5mA$ $P_o = 555mW$	EEx ia	IIB	560nF	10mH
		IIC	66nF	2.5mH
If concentrated capacitance and/or inductance are available, use the following values.	EEx ia	IIB	320nF	10mH
		IIC	60nF	2mH

1797-IE8 and -IE8NF UL, C-UL I/O Entity Parameters

If this product has the UL/C-UL mark, it has been designed, evaluated, tested, and certified to meet the following standards:


- UL 913, 1988, Intrinsically Safe Apparatus and Associated Apparatus for Use in Class I, II, and III Division 1, Hazardous (Classified) Locations
- UL 1203, Explosion-Proof and Dust-Ignition-Proof Electrical Equipment for Use in Hazardous (Classified) Locations
- UL 2279, Electrical Equipment for Use in Class I, Zone 0, 1, and 2 Hazardous (Classified) Locations
- UL 508, Industrial Control Equipment
- CSA C22.2 No. 157-92, Intrinsically Safe and Non-Incendive Equipment for Use in Hazardous Locations
- CSA C22.2 No. 30-M1986, Explosion-Proof Enclosures for Use in Class I Hazardous Locations
- CSA-E79-0-95, Electrical Apparatus for Explosive Gas Atmospheres, Part 0: General Requirements
- CSA-E79-11-95, Electrical Apparatus for Explosive Gas Atmospheres, Part 11: Intrinsic Safety “i”
- CSA C22.2 No. 14-95, Industrial Control Equipment

Wiring Methods

- Wiring method 1 - Each channel is wired separately.
- Wiring method 2 - Multiple channels in one cable, providing each channel is separated in accordance with the National Electric Code (NEC) or Canadian Electric Code (CEC).

Table 1

Wiring Method	Channel	Terminals	V _{oc} (V)	I _{sc} (mA)	V _t (V)	I _t (mA)	Groups	C _a (μF)	L _a (mH)
1 and 2	Any one channel e.g. ch0	0(+), 1(sig)	23.7	92.5	-	-	A, B, IIC	0.06	2.0
							C, E, IIB	0.18	8.0
							D, F, G, IIA	0.48	16.0
		1(sig), 2(-)	5	1.0	-	-	A, B, IIC	100	1000
							C, E, IIB	300	1000
							D, F, G, IIA	800	1000
		0(+), 1(sig), 2(-)	-	-	23.7	93.5	A, B, IIC	0.06	2.0
							C, E, IIB	0.18	8.0
							D, F, G, IIA	0.48	16.0



42055

IMPORTANT

A terminal base may or may not have an I/O module installed.

Hazardous (Classified) Location
Class I, Zones 0, 1, & 2 Groups IIC, IIB, IIA
Class I, Div. 1 & 2 Groups A, B, C, D
Class II, Div. 1 & 2 Groups E, F, G
Class III, Div. 1 & 2

Hazardous (Classified) Location
Class I, Zones 1 & 2 Groups IIC, IIB, IIA
Class I, Div. 1 & 2 Groups A, B, C, D

Any Simple Apparatus ② or I.S. device with Entity Concept parameters ① (V_{max} , I_{max} , C_i , L_i) appropriate for connection to associated apparatus with Entity Concept parameters listed in Table 1.




Table 2

Terminals	V_t (V)	I_t (mA)	Groups	C_a (μ F)	L_a (μ H)
Male Bus Connector	5.8	400	A-G	3.0	3.0

① The entity concept allows interconnection of intrinsically safe apparatus with associated apparatus not specifically examined in combination as a system when the approved values of V_{oc} and I_{sc} or V_t and I_t of the associated apparatus are less than or equal to V_{max} and I_{max} of the intrinsically safe apparatus and the approved values of C_a and L_a of the associated apparatus are greater than $C_i + C_{cable}$ and $L_i + L_{cable}$ respectively for the intrinsically safe apparatus.

② Simple apparatus is defined as a device which neither generates nor stores more than 1.2V, 0.1A, 20 μ J, or 25mW.

③ Wiring methods must be in accordance with the National Electric Code, ANSI/NFPA 70, Article 504 and 505 or the Canadian Electric Code CSA C22.1, Part 1, Appendix F. For additional information refer to ANSI/ISA RP12.6.

④ This module, 1797-IE8 or -IE8NF, must be used with terminal base 1797-TB3 or 1797-TB3S.

⑤ Terminals 3, 7, 11, 15, 20, 24, 28, 32, 36-39, and 46-49 shall not be connected.

⑥ **WARNING:** Substitution of components may impair intrinsic safety.
AVERTISSEMENT: La substitution de composant peut compromettre la sécurité intrinsèque.

1797-IE8 and -IE8NF FM I/O Entity Parameters

If this product has the FM mark, it has been designed, evaluated, tested, and certified to meet the following standards:


- FM C1. No.3600:1998, Electrical Equipment for Use in Hazardous (Classified) Locations General Requirements
- FM C1. No.3610:1999, Intrinsically Safe Apparatus and Associated Apparatus for Use in Class I, II, III Division 1 Hazardous (Classified) Locations
- FM C1. No.3615:1989, Explosionproof Electrical Equipment General Requirements
- FM C1. No.3810:1989, 1995, Electrical and Electronic Test, Measuring and Process Control Equipment
- ANSI/NEMA 250, 1991, Enclosures for Electrical Equipment

Wiring Methods

- Wiring method 1 - Each channel is wired separately.
- Wiring method 2 - Multiple channels in one cable, providing each channel is separated in accordance with the National Electric Code (NEC).

Table 1

Wiring Method	Channel	Terminals	V _{oc} (V)	I _{sc} (mA)	V _t (V)	I _t (mA)	Groups	C _a (μF)	L _a (mH)
1 and 2	Any one channel e.g. ch0	0(+), 1(sig)	23.7	92.5	-	-	A, B	0.15	4.0
							C, E	0.45	12.0
							D, F, G	1.20	32.0
		1(sig), 2(-)	5	1.0	-	-	A, B	100	1000
							C, E	300	1000
							D, F, G	800	1000
		0(+), 1(sig), 2(-)	-	-	23.7	93.5	A, B	0.15	4.0
							C, E	0.45	12.0
							D, F, G	1.20	32.0



IMPORTANT

A terminal base may or may not have an I/O module installed.

Hazardous (Classified) Location
Class I, Zones 0 Groups IIC
Class I, Div. 1 Groups A, B, C, D
Class II, Div. 1 Groups E, F, G
Class III, Div. 1

Hazardous (Classified) Location
Class I, Zones 1 Groups IIC
Class I, Div. 1 Groups A, B, C, D

Any Simple Apparatus ② or FM approved device with Entity Concept parameters $\Phi(V_{max}, I_{max}, C_p, L_p)$ appropriate for connection to associated apparatus with Entity Concept parameters listed in Table 1.




Table 2

Terminals	V_t (V)	I_t (mA)	Groups	C_a (μF)	L_a (μH)
Male Bus Connector	5.8	400	A-G	3.0	3.0

① The entity concept allows interconnection of intrinsically safe apparatus with associated apparatus not specifically examined in combination as a system when the approved values of V_{oc} and I_{sc} or V_t and I_t of the associated apparatus are less than or equal to V_{max} and I_{max} of the intrinsically safe apparatus and the approved values of C_a and L_a of the associated apparatus are greater than $C_i + C_{cable}$ and $L_i + L_{cable}$ respectively for the intrinsically safe apparatus.

② Simple apparatus is defined as a device which neither generates nor stores more than 1.2V, 0.1A, 20μJ, or 25mW.

③ Wiring methods must be in accordance with the National Electric Code, ANSI/NFPA 70, Article 504 and 505. For additional information refer to ANSI/ISA RP12.6.




④ This module, 1797-IE8, must be used with terminal base 1797-TB3 or 1797-TB3S.

⑤ Terminals 3, 7, 11, 15, 20, 24, 28, 32, 36-39, and 46-49 shall not be connected.

⑥ **WARNING:** Substitution of components may impair intrinsic safety.

1797-OE8 Output Module**Specifications**

Number of Outputs	8 single-ended, non-isolated
IS Output Type	EEx ia IIB/IIC T4, AEx ia IIC T4 Class I, II, III Division 1 Groups A-G T4
IS Module Type	EEx ib IIB/IIC T4, AEx ib IIC T4, Class I Division 1 Groups A-D T4
Resolution	13 bit
Transfer Characteristics Accuracy at 20°C (68°F) Temperature Drift	0.1% of output signal range 0.010%/C of output signal range
Load Range Current Voltage Available at 22mA Load	0-22mA >11V 0-500Ω @ 22mA
Data Format	Configurable
Step Response to 99% of FS	4ms
Indicators	8 red fault indicators 1 green power
Output (Intrinsically Safe) (16 pin male and female flexbus connector)	$U_i \leq 5.8V$ dc $I_i \leq 400mA$ $L_i = \text{Negligible}$ $C_i \leq 1.35\mu F$
Isolation Path Output to Power Supply Output to Flexbus Output to Output Power Supply to Flexbus	Isolation Type Galvanic to DIN EN50020 Galvanic to DIN EN50020 None Galvanic to DIN EN50020
Power Supply (+V, -V Intrinsically Safe)	$U_i \leq 9.5V$ dc $I_i \leq 1A$ $L_i = \text{Negligible}$ $C_i = \text{Negligible}$
Module Field-Side Power Consumption	6.3W
Power Dissipation	5.4W
Thermal Dissipation	18.4 BTU/hr
Module Location	Cat. No. 1797-TB3 or -TB3S Terminal Base Unit
Conductors Wire Size	12 gauge (4mm ²) stranded maximum 1.2mm (3/64in) insulation maximum
Dimensions	46 x 94 x 75mm (1.8 x 3.7 x 2.95in)
Weight	200g (approximately)
Keyswitch Position	4

Environmental Conditions	
Operational Temperature	-20 to +70°C (-4 to +158°F)
Storage Temperature	-40 to +85°C (-40 to +185°F)
Relative Humidity	5 to 95% noncondensing
Shock	Tested to 15g peak acceleration, 11(+1)ms pulse width
Operating	Tested to 15g peak acceleration, 11(+1)ms pulse width
Non-Operating	Tested 2g @ 10-500Hz per IEC68-2-6
Vibration	
Agency Certification	
CENELEC	II (1) 2G EEx ia/ib IIB/IIC T4 II (1D) (2D)
UL, C-UL	Class I Division 1 & 2 Groups A-D T4 Class I Zone 1 & 2 AEx ib/[ia] IIC T4
FM	Class I Division 1 Groups A-D T4 Class I Zone 1 AEx ib/[ia] IIC T4
Certificates	
CENELEC	DMT 00 ATEX E 042 X 
UL, C-UL	UL Certificate Number 99.19699 c  US Class I Division 1 Hazardous
FM	FM Certificate Number 3009806 

1797-OE8 CENELEC I/O Entity Parameters

Signal output (+ to -) for ch 0 to ch 7 (terminals: 0-1; 4-5; 8-9; 12-13; 17-18; 21-22; 25-26; 29-30)

	Protection	Group	Allowed Capacitance	Allowed Inductance
$U_o = 21V$ $I_o = 93mA$ $P_o = 145mW$	EEx ia	IIB	1.27 μ F	10mH
		IIC	188nF	3mH
If concentrated capacitance and/or inductance are available, use the following values.	EEx ia	IIB	400nF	10mH
		IIC	80nF	2mH

1797-OE8 UL, C-UL I/O Entity Parameters

If this product has the UL/C-UL mark, it has been designed, evaluated, tested, and certified to meet the following standards:


- UL 913, 1988, Intrinsically Safe Apparatus and Associated Apparatus for Use in Class I, II, and III Division 1, Hazardous (Classified) Locations
- UL 1203, Explosion-Proof and Dust-Ignition-Proof Electrical Equipment for Use in Hazardous (Classified) Locations
- UL 2279, Electrical Equipment for Use in Class I, Zone 0, 1, and 2 Hazardous (Classified) Locations
- UL 508, Industrial Control Equipment
- CSA C22.2 No. 157-92, Intrinsically Safe and Non-Incendive Equipment for Use in Hazardous Locations
- CSA C22.2 No. 30-M1986, Explosion-Proof Enclosures for Use in Class I Hazardous Locations
- CSA-E79-0-95, Electrical Apparatus for Explosive Gas Atmospheres, Part 0: General Requirements
- CSA-E79-11-95, Electrical Apparatus for Explosive Gas Atmospheres, Part 11: Intrinsic Safety “i”
- CSA C22.2 No. 14-95, Industrial Control Equipment

Wiring Methods

- Wiring method 1 - Each channel is wired separately.
- Wiring method 2 - Multiple channels in one cable, providing each channel is separated in accordance with the National Electric Code (NEC) or Canadian Electric Code (CEC).

Table 1

Wiring Method	Channel	Terminal s	V _{oc} (V)	I _{sc} (mA)	V _i (V)	I _i (mA)	Groups	C _a (μF)	L _a (mH)
1 and 2	Any one channel e.g. ch0	0(+), 1(-)	21.0	100.0	-	-	A, B, IIC	0.08	2.0
							C, E, IIB	0.24	8.0
							D, F, G, IIA	0.64	16.0



IMPORTANT

A terminal base may or may not have an I/O module installed.

Hazardous (Classified) Location
Class I, Zones 0, 1, & 2 Groups IIC, IIB, IIA
Class I, Div. 1 & 2 Groups A, B, C, D
Class II, Div. 1 & 2 Groups E, F, G
Class III, Div. 1 & 2

Hazardous (Classified) Location
Class I, Zones 1 & 2 Groups IIC, IIB, IIA
Class I, Div. 1 & 2 Groups A, B, C, D




Table 2

Terminals	V_t (V)	I_t (mA)	Groups	C_a (μ F)	L_a (μ H)
Male Bus Connector	5.8	400	A-G	3.0	3.0

① The entity concept allows interconnection of intrinsically safe apparatus with associated apparatus not specifically examined in combination as a system when the approved values of V_{oc} and I_{sc} or V_t and I_t of the associated apparatus are less than or equal to V_{max} and I_{max} of the intrinsically safe apparatus and the approved values of C_a and L_a of the associated apparatus are greater than $C_i + C_{cable}$ and $L_i + L_{cable}$ respectively for the intrinsically safe apparatus.

② Simple apparatus is defined as a device which neither generates nor stores more than 1.2V, 0.1A, 20 μ J, or 25mW.

③ Wiring methods must be in accordance with the National Electric Code, ANSI/NFPA 70, Article 504 and 505 or the Canadian Electric Code CSA C22.1, Part 1, Appendix F. For additional information refer to ANSI/ISA RP12.6.

④ This module, 1797-OE8, must be used with terminal base 1797-TB3 or 1797-TB3S.

⑤ Terminals 2, 3, 6, 7, 10, 11, 14, 15, 19, 20, 23, 24, 27, 28, 31, 32, 36-39, and 46-49 shall not be connected.

⑥ **WARNING:** Substitution of components may impair intrinsic safety.
AVERTISSEMENT: La substitution de composant peut compromettre la sécurité intrinsèque.

1797-OE8 FM I/O Entity Parameters

If this product has the FM mark, it has been designed, evaluated, tested, and certified to meet the following standards:


- FM C1. No.3600:1998, Electrical Equipment for Use in Hazardous (Classified) Locations General Requirements
- FM C1. No.3610:1999, Intrinsically Safe Apparatus and Associated Apparatus for Use in Class I, II, III Division 1 Hazardous (Classified) Locations
- FM C1. No.3615:1989, Explosionproof Electrical Equipment General Requirements
- FM C1. No.3810:1989, 1995, Electrical and Electronic Test, Measuring and Process Control Equipment
- ANSI/NEMA 250, 1991, Enclosures for Electrical Equipment

Wiring Methods

- Wiring method 1 - Each channel is wired separately.
- Wiring method 2 - Multiple channels in one cable, providing each channel is separated in accordance with the National Electric Code (NEC).

Table 1

Wiring Method	Channel	Terminals	V _{oc} (V)	I _{sc} (mA)	V _t (V)	I _t (mA)	Groups	C _a (μF)	L _a (mH)
1 and 2	Any one channel e.g. ch0	0(+), 1(sig)	21.0	100.0	-	-	A, B	0.20	3.5
							C, E	0.60	10.5
							D, F, G	1.60	28.0



IMPORTANT

A terminal base may or may not have an I/O module installed.

Hazardous (Classified) Location
Class I, Zones 0 Groups IIC, IIB, IIA
Class I, Div. 1 Groups A, B, C, D
Class II, Div. 1 Groups E, F, G
Class III, Div. 1

Hazardous (Classified) Location
Class I, Zones 1 Groups IIC
Class I, Div. 1 Groups A, B, C, D

Any Simple Apparatus ② or FM approved device with Entity Concept parameters Φ (V_{max} , I_{max} , C_p , L_p) appropriate for connection to associated apparatus with Entity Concept parameters listed in Table 1.




Table 2

Terminals	V_t (V)	I_t (mA)	Groups	C_a (μF)	L_a (μH)
Male Bus Connector	5.8	400	A-G	3.0	3.0

- ① The entity concept allows interconnection of intrinsically safe apparatus with associated apparatus not specifically examined in combination as a system when the approved values of V_{oc} and I_{sc} or V_t and I_t of the associated apparatus are less than or equal to V_{max} and I_{max} of the intrinsically safe apparatus and the approved values of C_a and L_a of the associated apparatus are greater than $C_i + C_{cable}$ and $L_i + L_{cable}$ respectively for the intrinsically safe apparatus.
- ② Simple apparatus is defined as a device which neither generates nor stores more than 1.2V, 0.1A, 20μJ, or 25mW.
- ③ Wiring methods must be in accordance with the National Electric Code, ANSI/NFPA 70, Article 504 and 505. For additional information refer to ANSI/ISA RP12.6.
- ④ This module, 1797-OE8, must be used with terminal base 1797-TB3 or 1797-TB3S.
- ⑤ Terminals 2, 3, 6, 7, 10, 11, 14, 15, 19, 20, 23, 24, 27, 28, 31, 32, 36-39, and 46-49 shall not be connected.
- ⑥ **WARNING:** Substitution of components may impair intrinsic safety.

Notes:

A**Alarms**

- 1797-IE8 module 1-3
 - local fault 1-3, 1-6
 - overrange 1-3, 1-4
 - programming remote fault 1-6
 - remote fault 1-3, 1-5
 - underrange 1-3, 1-4
 - using fault mode with local fault alarm 2-2
 - using fault mode with remote fault alarm 2-2
 - using remote fault alarm to determine alarm levels 1-5

Analog Digital State

- 1797-OE8 module 2-8

Analog Fault State

- 1797-OE8 module 2-9

Area Classification

- defining 6-2
- hazard 6-2
- method 6-2
- temperature rating 6-2

B**Bit Descriptions**

- image table mapping 2-13

Bit/Word Description

- 4 output/4 input module 2-17

C**Calibration** 5-1

- 1797-IE8 module 5-6
- 1797-OE8 module 5-8
- module command words 5-2
- periodic 5-1
- tools 5-2
- tools and equipment 5-2

Communication Fault Behavior 4-7**ControlNet Ex Adapter** 2-7**ControlNet Network** 1-2, 4-2, 4-4**D****Data Format**

- 1797-IE8 module 2-4

Digital Fault State

- 1797-OE8 module 2-9

Drilling Dimensions

- wall/panel mounting 3-8

E**Entity Parameters**

- 1797-IE8 module A-3
- 1797-OE8 module A-11

European Union Directives

- compliance to 3-2
- EMC directive 3-2
- Ex directive 3-2

F**Fault Mode**

- 1797-IE8 module 2-2
 - enabling/disabling local fault alarm 2-2
 - enabling/disabling remote fault alarm 2-2

Functional and Intrinsic Safety**Parameters**

- 1797-IE8 module 6-4

H**High Low Error Level**

- 1797-IE8 module 2-3

I**Idle State Behavior** 4-7**Image Table Mapping** 2-13

- 1797-IE8 bit/word descriptions 2-15
- 1797-IE8 module 2-14
- 1797-OE8 bit/word descriptions 2-17
- 1797-OE8 module 2-16

Input Data Behavior

- upon module removal 4-8

Input Filter Cutoff

- 1797-IE8 module 2-3

Installation 3-4

- module 3-9

Intrinsic Safety Entity Verification 6-6

K**Keyswitch**

using on the terminal base unit 3-9

L**Latch Retry Mode**

1797-OE8 module 2-8

Local Fault Mode

1797-OE8 module 2-7

Loop Functionality Verification 6-4**M****Module**

shipping state

calibration 5-1

Module I/O Mapping 4-4**Module Installation** 3-9**Module Status**

indicators 1-3

Mounting

on terminal base 3-9

Mounting Kit

cat. no. 1794-NM1 3-7

Mounting the Module

on 1797-TB3 or 1797-TB3S terminal base
unit 3-9

O**Output Enable**

1797-OE8 module 2-7

P**Panel/Wall Mounting** 3-7

drilling dimensions 3-8

Power

assigning power supplies 6-7

power supply considerations 6-9

Programming Software 4-2**Protection Method**

encapsulation 6-3

flameproof 6-3

increased safety 6-3

intrinsic safety 6-3

selecting 6-3

R**Remote Transmitter Error Up or Down**

1797-IE8 module 2-3

Removal and Insertion Under Power

(RIUP) 3-4

S**Scheduled Data-Transfer**

over the FLEX Ex backplane 4-3

Specifications

1797-IE8 module A-1

T**Tools**

calibration 5-2

Troubleshooting

1797-IE8 module indicators 7-1

1797-OE8 module indicators 7-2

module indicators 1-3

module repair 7-2

Two-Wire Transmitter Devices

connecting to the 1797-IE8 module 3-12

U**Unscheduled Data-Transfer**

over the FLEX Ex backplane 4-3

W**Wall/Panel Mounting** 3-7**Wiring**

1797-IE8 module 3-11, 3-12

1797-OE8 module 3-13, 3-14

1797-TB3 and 1797-TB3S terminal base
units 3-10



How Are We Doing?

Your comments on our technical publications will help us serve you better in the future.
Thank you for taking the time to provide us feedback.

You can complete this form and mail (or fax) it back to us or email us at
RADocumentComments@ra.rockwell.com

Pub. Title/Type FLEX Ex Analog Modules

Cat. No. 1797-IE8, -IE8NF, and -OE8 Pub. No. 1797-6.5.1 Pub. Date May 2005 Part No. 957831-49

Please complete the sections below. Where applicable, rank the feature (1=needs improvement, 2=satisfactory, and 3=outstanding).

Overall Usefulness	1	2	3	How can we make this publication more useful for you?
Completeness (all necessary information is provided)	1	2	3	Can we add more information to help you?
				procedure/step illustration feature
				example guideline other
				explanation definition
Technical Accuracy (all provided information is correct)	1	2	3	Can we be more accurate?
				text illustration
Clarity (all provided information is easy to understand)	1	2	3	How can we make things clearer?
Other Comments				You can add additional comments on the back of this form.

Your Name _____
Your Title/Function _____
Location/Phone _____

Would you like us to contact you regarding your comments?
___ No, there is no need to contact me
___ Yes, please call me
___ Yes, please email me at _____
___ Yes, please contact me via _____

Return this form to: Rockwell Automation Technical Communications, 1 Allen-Bradley Dr., Mayfield Hts., OH 44124-9705

Fax: 440-646-3525 Email: RADocumentComments@ra.rockwell.com

PLEASE FASTEN HERE (DO NOT STAPLE)

Other Comments

PLEASE FOLD HERE

PLEASE REMOVE

NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO. 18235 CLEVELAND OH

POSTAGE WILL BE PAID BY THE ADDRESSEE



**Rockwell
Automation**

**1 ALLEN-BRADLEY DR
MAYFIELD HEIGHTS OH 44124-9705**



Rockwell Automation Support

Rockwell Automation provides technical information on the web to assist you in using our products. At <http://support.rockwellautomation.com>, you can find technical manuals, a knowledge base of FAQs, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools.

For an additional level of technical phone support for installation, configuration and troubleshooting, we offer TechConnect Support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://support.rockwellautomation.com>.

Installation Assistance

If you experience a problem with a hardware module within the first 24 hours of installation, please review the information that's contained in this manual. You can also contact a special Customer Support number for initial help in getting your module up and running:

United States	1.440.646.3223 Monday – Friday, 8am – 5pm EST
Outside United States	Please contact your local Rockwell Automation representative for any technical support issues.

New Product Satisfaction Return

Rockwell tests all of our products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned:

United States	Contact your distributor. You must provide a Customer Support case number (see phone number above to obtain one) to your distributor in order to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for return procedure.

www.rockwellautomation.com

Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 1797-6.5.1 - May 2005

Supersedes Publication 1797-6.5.1 - April 1999

PN 957831-49

Copyright © 2005 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.